


Model No. EE-6604S / EE-6604B

Long platform scissor lift, Low Profile
Electrical Leveling
Lifting Capacity 4000KG

Installation, Operation
and Parts Manual



EAE



Distributed by

Please read this entire manual carefully and completely before installation or operation of the lift.

DATE: 20/11/2024

www.eae-ae.com

IMPORTANT NOTES

Before start up, connecting and operating EAE products, it is absolutely essential that the operating instructions/owner's manual and, in particular the safety instructions are studied carefully. By doing so you can eliminate any uncertainties in handling EAE products and thus associated safety risks up front; something which is in the interest of you own safety and will ultimately help avoid damage to the device, When an EAE product is handed over to another person, not only the operating instructions but also the safety instructions and information on its designated use must be handed over to the person.

By using the product you agree the following conditions:

Copy right

The enclosed instructions are the property of EAE or its supplier, and are protected against duplication and reproduction by copyright laws, international agreements, and other domestic legislation. The reproduction or disclosure of instructions or an extract thereof is prohibited and offenders are liable to prosecution; EAE reserves the right or initiates criminal proceedings and asserts claims for damages in the event of infringements.

Warranty

The use of non-approved hardware will result in a modification of our products and thus to the exclusion of any liability or warranty, even if such hardware has been removed again in the interim.

It is not permissible to make any changes to our products and these are not only to be used together with genuine accessories and genuine replacement parts. Otherwise any warranty claims will be invalid.

Liability

The liability of EAE is limit to the amount that the customer has actually paid for this product. This exclusion of liability does not apply to damages caused through willful misconduct or gross negligence on the part of EAE.

All information in this manual is believed to be correct at time of publication.

EAE reserves the right to amend and alter technical data and composition without prior notice.

Please confirm at time of ordering.

IMPORTANT NOTES	2
SAFETY NOTES	4
1.1 Operation of lifting platforms	4
1.2 Checking of the lifting platforms.....	4
1.3 Important safety notices	5
1.4 Warning labels	6
1.5 Potential safety risks	7
1.6 Noise level.....	7
PACKING, STORAGE AND TRANSPORTATION	8
2.1 The lift was dismantled into 3 parts for transportation	8
2.2 Storage	8
2.3 Lifting and handling	8
PRODUCT DESCRIPTIONS	9
3.1 General descriptions	9
3.2 Construction of the lift.....	9
3.3 Dimensions.....	10
3.4 Safety device descriptions	14
3.5 Technical data	14
INSTALLATION INSTRUCTIONS	15
4.1 Preparations before installation	15
4.2 Installation attentions.....	16
4.3 General Installation Steps	16
4.4 Items to be checked after installation.	19
OPERATION INSTRUCTIONS	19
5.1 Precautions	19
5.2 Descriptions of control panel.....	20
5.3 Flow chart for operation	20
5.4 Operation instructions.....	21
TROUBLE SHOOTING	22
MAINTENANCE	23
Annex 1, Floor Plan	26
Annex 2, Electrical schemes and parts list.....	27
Annex 3, Hydraulic schemes and parts list	32
Annex 4, Pneumatic scheme and parts list.....	35
Annex 5, Mechanically exploded drawings and parts list.....	36

SAFETY NOTES

1.1 Operation of lifting platforms

This lift is specially designed for lifting motor vehicles. Users are not allowed to use it for any other purposes. The applicable national regulations, laws and directives must be observed.

Only users aged 18 or above who have been instructed on how to operate the lifting platform and have proven their ability to do so to the owner are to be entrusted with unsupervised operation of lifting platforms. The task of operating the lifting platforms must be granted in writing.

Before loading a vehicle onto the lifting platform, users should study the original operation instructions and familiarize themselves with the operating procedures in several trial runs.

1.2 Checking of the lifting platforms

Checks are to be based on the following directives and regulations:

- Basic principles for testing lifting platforms
- The basic safety requirements stipulated in the directive 2006/42/EC
- Harmonized European standards
- The applicable accident prevention regulations

The checks are to be organized by the user of the lifting platform. The user is responsible for appointing an expert or qualified person to perform checking.

The user bears special responsibility if employees of the company are appointed as experts or qualified persons.

1.2.1 Scope of checking

Regular checking essentially involves performing a visual inspection and a functional test. This includes checking the condition of the components and equipment, checking that the safety systems are complete and functioning properly and that the inspection log book is completely filled in. The scope of exceptional checking depends on the nature and extent of any structural modification or repair work.

1.2.2 Regular checking

After initial commissioning, lifting platforms are to be checked by a qualified person at intervals of not longer than one year.

A qualified person is somebody with the training and experience required to possess sufficient knowledge of lifting platforms and who is sufficiently familiar with the pertinent national regulations, accident prevention regulations and generally acknowledged rules of engineering to be able to assess the safe operating condition of lifting platforms.

1.2.3 Exceptional checking

Lifting platforms with a lift height of more than 2 meters and lifting platforms intended for use with people standing under the load bearing elements of the load are to be checked by an expert prior or reuse following structural modifications and major repairs to load bearing components.

An expert is somebody with the training and experience required to possess specialist knowledge of lifting platforms and who is sufficiently familiar with the pertinent national work safety regulations, accident prevention regulations and generally acknowledged rules

of engineering to be able to check and give an expert opinion on lifting platforms.

1.3 Important safety notices

1.3.1 Recommend for indoor use only. DO not expose the lift to rain, snow or excessive moisture.

1.3.2 Only use this lift on a surface that is stable, level and dry and not slippery, and capable of sustaining the load. Do not install the lift on any asphalt surface.

1.3.3 Read and understand all safety warnings before operating the lift.

1.3.4 Do not leave the controls while the lift is still in motion.

1.3.5 Keep hands and feet away from any moving parts. Keep feet clear of the lift when lowering.

1.3.6 Only these properly trained personnel can operate the lift.

1.3.7 Do not wear unfit clothes such as large clothes with flounces, ties, etc., which could be caught by moving parts of the lift.

1.3.8 To prevent evitable incidents, surrounding areas of the lift must be tidy and with nothing unsecured.

1.3.9 The lift is simply designed to lift the entire body of vehicles, with its maximum weight within the lifting capacity.

1.3.10 always insure the safety locks are engaged before any attempt to work near or under the vehicle. Never remove safety related components from the lift. Do not use if safety related components are damaged or missing.

1.3.11 do not rock the vehicle while on the lift or remove any heavy component from vehicle that may cause excessive weight shift.

1.3.12 Check at any time the parts of the lift to ensure the agility of moving parts and the performance of synchronization. Ensure regular maintenance and if anything abnormal occurs, stop using the lift immediately and contact our dealers for help.

1.3.13 Lower the lift to its lowest position and do remember to cut off the power source when service finishes.

1.3.14 do not modify any parts of the lift without manufacturer's advice.

1.3.15 if the lift is going to be left unused for a long time, users are required to:

- a. Disconnect the power;
- b. Empty the oil tank;
- c. Lubricate the moving parts with grease.

WARNING: The warnings, cautions and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.




Attention: For environment protection, please dispose the disused oil in a proper way.

1.4 Warning labels

All safety warning labels are clearly depicted on the lift to ensure that the operator is aware of and avoid the dangers of using the lift in an incorrect manner. The labels must be kept clean and they have to be replaced if detached or damaged. Please read carefully the meaning of each label and memories them for future operation.

SAFETY ADVICE

540101444

 <p style="text-align: left; padding-left: 10px;">Only trained personnel are allowed to operate the lift.</p>	<p style="text-align: left; padding-left: 10px;">Always keep lift area clear when lowering or raising vehicle.</p> 
 <p style="text-align: left; padding-left: 10px;">Do not try to raise a vehicle exceeds the rated capacity.</p>	<p style="text-align: left; padding-left: 10px;">Never raise or lower a vehicle with one side platform.</p> 
 <p style="text-align: left; padding-left: 10px;">Watch closely the vehicle during raising or lowering.</p>	<p style="text-align: left; padding-left: 10px;">It is not allowed to work under the vehicle if safety teeth are not engaged.</p> 
 <p style="text-align: left; padding-left: 10px;">Make sure that two platforms are of equal height from the floor when safety teeth engaged.</p>	<p style="text-align: left; padding-left: 10px;">Avoid excessive rocking of vehicle while on lift.</p> 
 <p style="text-align: left; padding-left: 10px;">Do not climb onto the lift platforms or raised vehicle during lifting or lowering.</p>	<p style="text-align: left; padding-left: 10px;">Always keep the lift pit clean and clear of any objects or contaminants.</p> 
 <p style="text-align: left; padding-left: 10px;">Do not change the safety mechanism.</p>	<p style="text-align: left; padding-left: 10px;">Carryout maintenance regularly as indicated in the manual.</p> 

1.5 Potential safety risks

1.5.1 Mains voltage



Insulation damage and other faults may result in accessible components being live

Safety measures:

- Only ever use the power cord provided or a tested power cord.
- Replace wires with damaged insulation.
- Do not open the operating unit.

1.5.2 Risk of injury, danger of crushing



In the event of excessive vehicle weight, incorrect mounting of the vehicle or on removing heavy object, there is a risk of the vehicle falling off the lifting platform or tipping up.

Safety measures:

- The lifting platform is only ever to be employed for the intended purpose.
- Carefully study and heed all the information given in Section 1.4.
- Observe the warning notices for operation.

1.6 Noise level

Noise emitted during operating the lift should be less than 70dB (A). For your health consideration, it is suggested to place a noise detector in your working area.

PACKING, STORAGE AND TRANSPORTATION

Packing, lifting, handling, transporting operations must be performed only by experienced personnel with appropriate knowledge of the lift and after reading this manual.

2.1 The lift was dismantled into 3 parts for transportation

Name	Packed by	Dimension(mm)	Weight(kg)	Quantity
Control cabinet	Wooden case	510*480*1300	Approx.84	1
Power side platform	Steel bracket	5100*890*380	Approx.1200	1
The secondary platform	Steel bracket	5100*890*380	Approx.1200	1
Ramp	Bubble film	1300*680*250	Approx.106	1

2.2 Storage

The packs must be kept in a covered and protected area in a temperature range of -10°C to $+40^{\circ}\text{C}$. They must not be exposed to direct sunlight, rain or water.

Stacking the packs

We advise against stacking because the packs are not designed for this type of storage. The narrow base, heavy weight and large size of the packs make stacking difficult and potentially dangerous.



If stacking is unavoidable, use all appropriate precautions:

- never stack to more than 2 meters in height.
- never make stacks of single packs. Always stack pairs of packs in a cross pattern so that the base is bigger and the resulting stack is more stable. Once the stack is complete, restrain it using straps, ropes or other suitable methods.

A maximum of two packs can be stacked on lorries, in containers, and in railway wagons, on condition that the packs are strapped together and restrained to stop them falling.

2.3 Lifting and handling

The packs can be lifted and transported only by using lift trucks. **Never attempt to hoist or transport the unit using lifting slings.**



Opening the packs

When the lift is delivered make sure that it has not been damaged during transportation and that all the parts specified on the packing list are present.

Packs must be opened adopting all the precautions required to avoid injury to persons (keep at a safe distance when cutting the straps) or damage to parts of the machine (be careful that no parts are dropped while you are opening the packing)

Take special care with the hydraulic power unit, the control panel and the platform cylinder.

PRODUCT DESCRIPTIONS

3.1 General descriptions

It is wheel support vehicle lift for road vehicles. The lifting system works with hydraulic gear pump delivering oil to push upwards pistons of oil cylinders. Thus, support scissor brackets of the lift rise accordingly.

Key features:

Low profile runway.

24V safe operation voltage.

Max height and safe descent limit switch.

With Synchronization protective device.

Anti-surge restrictive valve.

Long slip plate and adjustable turntable position.

Reserved tracks for optional rolling jacks.


Automatically engaged mechanical locking unit.

3.2 Construction of the lift

EE-6604B, Platforms with front recesses and rear slip plates.





EE-6604S, Flat platforms




3.3 Dimensions


EE-6604S-48L




EE-6604S-50L


EE-6604B-48L



EE-6604B-50L


3.4 Safety device descriptions



NO.	Safety device	Function
1	Anti-surge valve	Slow down the falling speed of lifting platform in case there is leakage of hydraulic oil hoses.
2	Mechanical lock for lifting platform	Protect the lifting platform from falling down in case oil cylinders loss forces caused by break down of hydraulic system.
3	24V operation voltage	Safety voltage for operators.
4	Tip-up protection for lifting platforms	Protect lifting platform from tipping-up, in case load on it is not evenly distributed.
5	Limit switch for safe descent	Stop lowering at safety height above ground.

3.5 Technical data

Rated capacity	4000kg
Full raised height	1900mm
Full lowered height	180mm
Full raised time (with rated load)	Approx.60s (3Ph,3.5kW motor)
Full lowered time (with rated load)	Approx.55s
Hydraulic working pressure	Approx.23MPa
Pneumatic working pressure	6-8 Bar
Oil tank volume	18L

INSTALLATION INSTRUCTIONS

4.1 Preparations before installation

4.1.1 Space requirements.

Refer to 3.3 for the dimensions of the lift. There must also be a clearance of at least 1 meter between the lifting platform and fixed elements (e.g. wall) in all lifting positions. There must be sufficient space at the ends of the lifting platform for driving vehicles on and off.

To stop vehicles colliding with the ceiling, it is advisable to fit an overhead light barrier in low ceiling buildings.

4.1.2 Foundations and connections

The user must have the following work performed before erecting the lift.

- Construction of the foundation following consultation with the manufacturer's customer service or an authorized service agent. Routing of the wiring to the installation location. **The user must provide fuse protection for the connection. Electrical system connection must be done by licensed technicians. Requirements for power supply cable of the installation site: at least 2.5mm² wire core for 3Ph power and 4.0mm² wire core for 1Ph power.**
- Refer also to the corresponding information on the name plate and in the operation instructions. **Before doing electrical connection, make sure the lift is electrically adapt to the local power supply.**
- Routing of the compressed air connection to the installation location. The user must install a service unit upstream of the connection.

4.1.3 Foundations preparations

To ensure stability and safety under load, the lift shall be installed with the base frame being in direct and firm contact with the concrete foundation. Don't attempt to fix the base frame directly onto floor with ceramic and other decorated surfaces otherwise you put the lift into a very dangerous situation.

Please refer to Annex 1 for floor dimensions.

4.1.4 Tools and equipment needed for installation

Tool Description	Specification	Qty
Electrical drill	With D16 and D18 drill bit.	1
Open spanner	D17-19mm	2
Adjustable spanner	bigger than D30mm	1
Cross socket screw driver	PH2	1
Quick spanner handle adapter/ Ratchet		1
Socket spanner	D24mm	1
Levelling device		1
Hammer	10 pounds	1
Truck lift	Capacity more than 2500kg	1
Lifting string	Capacity, 1000kg	2

Tool Description	Specification	Qty
Lifting string	Capacity, 2000kg	1
Torque spanner	MD400	1

4.1.5 Checking parts

Unfold the package and check if any parts missed as per the following list. Do not hesitate to contact us in case any parts missed, but if you do not contact us and insist installing upon the lack of some parts, we as well as our dealers will not bear any responsibility for this and will charge for any parts subsequently demanded by the buyer.

S/N	Description	Specification	Qty
1	Lifting platform	6604	2
2	Expansion bolt	M16*120	16
3	Control cabinet	3.5kW	1
4	Drive-on ramp	6604V2-A9	2
5	Protective cover A(L=2200)	6604V2-A13	1
6	Protective cover B(L=1000)	6604V2-A14	1
7	Protective cover C(L=1000)	6604V2-A15	1
8	Protective cover D(L=1000)	6604V2-A16	1
9	Cross socket cap head tapping screw	ST4.8*35	20
10	Plastic expansion tube	M10*40	20
11	Cross socket cap head screw	M6*12	4
12	Hex nut	M6	4
13	Flat washer	M6	4

4.2 Installation attentions

4.2.1 Tighten all hydraulic and electrical connections.

4.2.2 Tighten all screws, nuts and bolts.

4.2.3 Do not place any vehicle on the lift in the case of trial running.

4.3 General Installation Steps

ONLY TRAINED AND QUALIFIED INSTALLERS CAN PERFORM LIFT INSTALLATION DUTIES.

Step 1: Dismantle the package and place lifting platforms onto initially prepared installation foundation using a forklift and lifting straps.

Raise the platform by using a forklift and 2 lifting straps until the mechanical lock is engaged. Dismantle the bolts that fix the platform and its wooden package and then hoist the platform onto the expected installation site.

Attention 1: Avoid scratching the painting surface and hoses.

Attention 2: Before hoisting, make sure the hoses and wires are well protected against damage.

Attention 3: It is necessary to hold the platform during the hoisting process. Irrelevant person is not allowed in installation area.

Step 2: Connect hydraulic oil hoses.

Connect the oil hoses fittings to the power unit as per the diagram for oil hose connection. Annex 3.

Attention: Connect as per the marks on the hoses and do not contaminate the hydraulic components during the connection.

It must be taken adequate care that all fittings are securely tightened.
Severe leaking will occur if the hose fittings are not properly tightened.

Step 3: Connect the pneumatic release system

Step 3: Connect the pneumatic release system

Connect the pneumatic release system by the diagram of air hose connection in Annex 4.

Attention: Do not contaminate the pneumatic components during the connection.

Set the pneumatic pressure at 6-8 bars.

Push upward the button indicated in the following fig and turn the button until the hand of the pressure meter points to the NUMBER "6" .

Push the button down thereafter.



It is suggested to add ISO VG32 mechanical oil into the oil tank.
Adjust the oil dipping quantity using the button on top of the oil cup.

Step 4: Connect electrical wires.

Refer to electrical connection diagram before making the connection.

Attention: electrical system connection must be done by qualified electricians.

Connect the wire connectors for raising and lowering limit switches

Connect the power supply cable to external electricity supply.

(For three phase power supply, if the lift doesn't raise and the motor may turn in the wrong direction, in such event, interchange wires U, V in the control cabinet).

Step 5: Fill with hydraulic oil.

CLEAN AND FRESH OIL ONLY. DON'T FILL THE TANK COMPLETELY FULL.

Lift must be fully lowered before changing or adding hydraulic oil

Normally it needs 22 liters of hydraulic oil.

Initially, fill the tank full with about 18L of hydraulic oil. Run the lift for several cycles and add another 4L into the tank.

Note: It is suggested to use HM NO.46 hydraulic oil.

Use HM NO.32 hydraulic oil when average temperature is below 10°C.

Change the oil 6 months after initial use and change once per year thereafter.

Step 6: Levelling


Refer to 5.2 and 5.4 to get familiar with lift controls.

Turn SA2 to "OFF" mode before levelling operation.


Check the connection of the hydraulic and electrical system before levelling operation

- 1) Turn SA1 to working mode and push the button UP to raise both wheel-support platforms to the maximal height.
- 2) Keep pushing the UP button for 1 more minute and then lower the platform completely to the bottom.
- 3) Push the UP button to raise the platforms to the maximal height again and keep pushing the UP button for 20 more seconds.
- 4) Push the Up and Down button to check the synchronization. Normally, the two platforms have been synchronized by this step.
- 5) Manually level the platform in case the level deviation is less than 20mm.
- 5.1) Turn SA1 to "Levelling" mode.

Turn on one of the two levelling valves and push the UP or DOWN button to adjust the height of a single platform until it is at the same level with the other platform. Turn off the valve before normal raising or lowering.


Step 7: Fix base frames with expansion bolts.

- ① Before anchoring, it is necessary to check again the position for each base plates by referring to the dimension scheme as well as the corresponding installation requirements.
- ② Drill holes using D16 carbide tipped masonry drill bit. Make sure to drill vertically down.
- ③ Clean the hole and check again the position of the base frame to ensure they are correctly positioned.
- ④ Use a spirit level to check the vertical alignment of the two adjacent base plates. Make adjustment when necessary to assure they are at same level.
- ⑤ Impact and drive anchoring bolt into hole until nut and washer contact base.
- ⑥ Tighten the nut with torque wrench to 80Nm.

Step 8: Fix oil hose protection covers.


4.4 Items to be checked after installation.


S/N	Check items	YES	NO
1	Screw torque of expansion bolts : 60-80Nm;		
2	Rising speed ≥ 20 mm/s;		
3	Noise with rated load ≤ 75 dB(A);		
4	Grounding resistance: not bigger than 4Ω ;		
5	Height difference of the two platform ≤ 5 mm;		
6	Mechanical locks are robust and synchronized when running with rated load ;		
7	If the control button works as "hold to run"?		
8	If limit switches work well?		
9	If grounding wire is connected?		
10	If the lift rises and lowers smoothly?		
11	If there is no abnormal notice during running with rated load?		
12	If there is no oil leakage when running with rated load?		
13	If there is no air leakage when running with rated load?		
14	If expansion bolts, nuts or circlips are well secured?		
15	If max lifting height is reached?		
16	If Safety advices, name plate and logos are clear?		

OPERATION INSTRUCTIONS

5.1 Precautions


- ONLY authorized persons are permitted in the lift area.
- Do not try to raise the vehicle with excessive length or width. Otherwise there is risk of vehicle falling from lift.
- Inspect the space above and below the load and the loading carrying devices. It shall be free of obstructions before operating.
- Before raising operation, run the lift without load for a complete cycle to ensure it is in good condition.
- Before lifting the vehicle and during all operations on the vehicle, make sure that it is properly stopped by the hand brake.
- Check the vehicle after raising a short distance to ensure that it is correctly and safely positioned.
- It is forbidden for people to stand in the field of motion during raising or lowering movement.
- The load carrying device shall be observed by the operator throughout the motion of the lift.
- Engage the safety locking mechanism before entering under the raised vehicle.
- Avoid excessive rocking of vehicle while on the lift
- Do not climb onto the load or load carrying device when they are raised.

5.2 Descriptions of control panel



POS.	Description	Function
FA	Alarm buzzer	Safety warning
SB1	UP button	Control the rising movement
SB4	LOCK button	Engage mechanical locking unit
SB2	DOWN button	Control the initial lowering movement
SB3	DOWN button	Control the final lowering movement
SB	Emergency stop	Stop power in emergency cases
HL	Power indicator	Show if power is on
QS	Main switch	Power on /off
SA1	Selection switch	Control working or levelling mode
SA2	Selection switch	Turn on or off the infrared synchronization protective device

5.3 Flow chart for operation



5.4 Operation instructions

The lift must be only used in a static position for lifting and lowering vehicles. Only use this lift on a surface that is stable and capable of sustaining the load. Do not install the lift on any asphalt surface.

To avoid personal injury and/or property damage, permit only trained personnel to operate the lift. After reviewing these instructions, get familiar with lift controls by running the lift through a few cycles before loading vehicle on lifting platform.

Always lift the vehicle using all four adapters. Never raise just one end, one corner or one side of vehicle.

The normal users are not allowed to open the door of control cabinet. Selection switches in the control cabinet need to be turned to 'working' and "infrared on" before using the lift to raise vehicles.

Raise the lift

Make sure vehicle is neither front nor rear heavy and center of balance should be centered over the lift.

1. Drive and park the vehicle midway between two platforms. Make sure the vehicle is correctly positioned and secured against moving.
2. Push the "UP" button on the control panel to lift the vehicle a bit higher from the ground and check again if the vehicle is in a safe position.
3. Raise the vehicle to the expected height and push the "Safety Lock" button to ensure the mechanical safety lock is engaged and check again the stability before performing maintenance or repair work.

Lower the lift

When lowering the lift pay careful attention that all personnel and objects are kept clear.

1. Push "DOWN I" button to lower the lift. Firstly, the lift will automatically rise to disengage the mechanical locks. It will stop lowering when the platform lowers to a distance about 600mm off the ground.
2. Push "DOWN II" button to continue lowering the platforms. Meanwhile the buzz alarms.

Attention: In the case the lift runs unsynchronously with the deviation of height exceeds 60 mm in lifting or lowering process, the synchronization protective device will be activated to stop any raising or lowering movement. In this case the normal operator needs to ask professional help from the maintenance operator to restore the lift to normal working condition.

Restore to the normal working status.

Open the door of the control cabinet;

Turn SA2 to OFF status;

PUSH DOWN I and DOWN II button to lower till the bottom position;

Level until both platform are synchronized. (Refer to **Step 6: Levelling**)

Turn SA2 to ON status.

SA2: Control on or off for synchronization protection device.

TROUBLE SHOOTING

ATTENTION: If the trouble could not be fixed by yourself, do not hesitate to contact the distributor or manufacturer for help.


We will offer our service at the earliest time we can. Meanwhile the troubles will be judged and solved much faster if more details or pictures of the trouble are provided.

TROUBLES	POSSIBLE CAUSES	SOLUTIONS
Motor does not run and will not raise.	Loose wire connection	Check and make a good connection.
	Burnt motor.	Replace it.
	Damaged limit switch or its wire connection is loose.	Adjust or replace the limit switch.
Motor runs but will not raise.	The motor run reversely.	Check the wire connection.
	Overflow valve is not well screwed up or jammed.	Clean or make adjustment
	Damaged gear pump.	Replace it.
	Too low oil level.	Add oil.
	The hose connection is loose.	Tighten it.
	The cushion valve is not well screwed up or jammed.	Clean or make adjustment
Platforms go down slowly after being raised.	The oil hose leaks.	Check or replace it.
	Untightened oil cylinder.	Replace the seal.
	The single way valve leaks.	Clean or replace it.
	Solenoid valve fails to work well.	Clean or replace it.
	Unloading valve leaks.	Check and adjust the tightness.
Raising too slow.	Jammed oil filter	Clean or replace it.
	Too low oil level.	Add oil.
	The overflow valve is not adjusted to the right position.	Make adjustment.
	Too hot hydraulic oil (above 45°) .	Change the oil.
	Abraded seal of the cylinder	Replace the seal.
Lowering too slow.	Jammed throttle valve	Clean or replace it.
	Dirty hydraulic oil	Clean or replace it.
	Jammed anti-surge valve	Change the oil.
	Jammed oil hose	Clean it.

MAINTENANCE

Implementing consistent, low-cost routine maintenance is essential for ensuring the safe and reliable operation of your lift. Adhere to the prescribed maintenance schedule. Intervals could be adjusted based on actual workload and usage frequency.

Essential Pre-Use Task: Lubricate all moving parts with No.1 lithium grease.



S/N	Components	Methods	Period
1	Control buttons	Check if control buttons work as "hold- to -run " and check if they work as the function indicated.	Every day
2-1	Max height limit switch (removed, no this switch for version with auto-bleeding cylinders)		
2-2	Limit switch for safe descent	Push DOWN I button, inspect and ensure that lifting platform stops descending at safety height above ground.	Every day
3	Pneumatic filter	Listen and inspect the filter to ensure no leakage. Inspect and ensure the water level is below its max limit mark and the oil level is above the minimum limit mark.	Every day
4	Hydraulic block and valves	Inspect if the valves leak or not. Clean or change the valve if any leakage.	Every day

S/N	Components	Methods	Period
5	Oil hoses and connectors	Inspect to ensure no leakage before using the lift.	Every day
6	Pneumatic hoses and connectors	Inspect to ensure no leakage before using the lift.	Every day
7	Mechanical safety catch	Check if both mechanical catches can engage and disengage effectively and synchronously by pushing control buttons.	Every day
8	Padding plate for the start roller	Check its tightness and add grease.	Every 1 month
9	Terminals in the control unit	Open the control unit, inspect the wire terminals and screw firmly if any terminals become loose.	Every 3 months
10	Joint shafts	Add grease into the oil cups.	Every 3 months
11	Anchored expansion bolts	Check with torque spanner. 80Nm	Every 3 months
12	Self-locking nut	Check with torque spanner. The torque should be no less than 330N.m.	Every 3 months
13	Lifting platform synchronization	Check the synchronization of both lifting platforms. Ensure both platforms ascend and descend synchronously.	Every day
14	Hydraulic oil	Change the oil 6 months after initial use and once per year thereafter. Inspect the hydraulic oil and change the oil if the oil becomes black or there is dirt in the oil tank.	Every year
15	Whole Lift	Running the lift for several cycles with and without rated load. The lift can run steadily and smoothly with no abnormal noise. Check the synchronization of both lifting platforms. Ensure both platforms ascend and descend synchronously.	Every 3 months

Rust Prevention

1. Always keep the painted surfaces dry and clean.

Permanent contact with liquids must be avoided.

Wipe any spilled liquids off platforms and crossbeams immediately.

Promptly remove debris and deposits known to damage to the paint and cause rust (e.g., de-icing salt, sand/soil/grit, industrial dust, aggressive deposits).

Cleaning Method

Use only lukewarm water with standard washing-up liquid or a mild, non-aggressive detergent. Apply with a sponge or soft brush.

Rinse thoroughly to remove all detergent residue.

Never use high-pressure jet washers, steam cleaners, abrasive cleaners, or chemical products.

Immediately dry the lift completely using a suitable cloth. Spray lightly with a wax-based or oil-based protective spray.

2. Regularly inspect the paintwork.



Avoid allowing sharp or hard metal components to scrape or impact the painted surfaces.



Avoid placing overheated light sources in proximity to the painted surfaces.



Deep scratches or damaged areas must be repaired promptly to prevent water ingress accelerating oxidation and rust formation.


Epoxy resin paint is recommended for repairs.

Consistent adherence to these maintenance requirements promotes optimal lift performance, enhances operational safety, and maximizes service life. Damage resulting from incorrect and poor maintenance is not covered by guarantee.

Annex 2, Electrical schemes and parts list










POS.	Code	Description	Qty
T	320101128	Transformer 380V400V415V-24V	1
T	320101127	Transformer 220V230V240V-24V	1
M		Motor	1
SQ1	320301003	Limit switch (no this switch for version with auto-bleeding cylinders)	1
SQ2	320302002	Proximity switch	1
SQ3	320307062	Infrared sensor switch	1
SQ4/SQ5	320307032	Micro switch	2
SA1	320303023	Selection switch	1
SA2	320303019	Selection switch	1
QS	320304001	Power switch	1
SB3	320401041	Button	1
SB1;SB2;SB4	320401044	Button	3
SB	320402002	Emergency stop	1
	320503002	Ground terminals	1
	320505006	Wire terminal	16
	320505011	Retaining chip	2
KA2,KA3	320601001	Relay	2
KA1	320601002	Relay	1
	320601011	Relay holder	3
	320601018	Relay feet fixer	6
KT	320602009	Integrated time relay	1
KT2	320602009	Integrated time relay	1
QF	320801001	Circuit breaker	1
QF1	320803001	Circuit breaker	1
QF2	320803005	Circuit breaker	1
KM	320901011	AC contactor	1
C	321001004	Capacitor	1
VD	321002001	Bridge rectifier	1
HL	321201001	Power indicator	1
FA	321202001	Alarm buzzer	1
SA	320305001	Rocker switch (OPTIONAL)	4
LED	321201021C	LED lamp (OPTIONAL)	4

**NOTE: The transformer is different for various voltages of power supply.
Please check with our customers service people when order spare parts.**


Annex 3, Hydraulic schemes and parts list


1. Oil tank 2. Oil sucking filter 3. Motor 4. Gear pump
 5. Relief valve 6. Non-return valve 7. Solenoid unloading valve 8. Restrictive valve 9. Tank lid
 10. Leveling valve 11. Cylinder connector 12. Master cylinder 13. Slave cylinder 14. Assisting valve



Pos.	Code	Description	Specification	Qty
C1	615019005	Tube connector B	6501-A4-B16	4
C2	615019006	Straight restrictive valve	6501-A4-B15	6
C3	310101010	Straight connector	G1/4---G1/4	5
C5	410210181	3-way connector	6603B-A9-B7	3
C6	410250271	4-way connector	6604B-A29	1
CD1	625000011	Master cylinder	YG90/102-50-625	2
CD2	625000012	Slave cylinder	YG75/85-45-625	2
CD3	625000025	Assisting cylinder	YG75-85-45-595	2
1	624002105	Oil hose	Φ 6,L=530	1
2	624001260	Oil hose	Φ 6,L=3800mm	1
3	624001281	Oil hose	Φ 6,L=2250mm	1
4	624001281	Oil hose	Φ 6,L=2250mm	1
5	624008216	Oil hose	Φ 6*R1AT, L=2200mm	1
6	624001815	Oil hose	Φ 6,L=1700mm	1
7	624001260	Oil hose	Φ 6,L=3800mm	1
8	624001045	Oil hose	Φ 6,L=530mm	1
9	624001846	Oil hose	Φ 6,L=600mm	1
10	624001093C	Oil hose	Φ 6,L=3700mm	3
11	624008208	Oil hose	Φ 6*R1AT, L=550mm	1
12	624001845	Oil hose	Φ 6,L=570mm	1


Pos.	Code	Description	Specification	Qty
13	624008217	Oil hose	Φ6*R1AT, L=4100mm	1




POS.	Code	Description	Specification	Qty	Note
1	330405027	Steel oil tank	18L	1	
2	201102002	Hex flange screw	M5*10	4	
3	202109064	Hex socket cylinder head screw	M6*30	4	
4	207103025	Composite washer	G1/4	3	
5	310101028	Shifting connector	G1/4 to M14x1.5	3	
6	330101008	Composite hydraulic block	YF-06	1	
7	320203001	Motor	380V-3.5KW-3PH-50HZ-2P	1	3.5KW
	320203005	Motor	400V/3.5KW -3PH-50HZ-2P	1	3.5KW
	320203006	Motor	415V/3.5KW -3PH-50HZ-2P	1	3.5KW
	320203007	Motor	220V/3.5KW -3PH-60HZ-2P	1	3.5KW
8	330301001	Cushion valve	HZYF-C1	1	
9	330302001	Single way valve	DYF-C	1	
10	330304001	Over flow valve	EYF-C	1	
11	330305002	Throttle valve	-	1	

POS.	Code	Description	Specification	Qty	Note
12	330308006	Solenoid unloading valve	DHF06-220H/DC24	1	
13	330308008	Leveling valve	DHF06-228H/DC24	2	
14	330401005	Oil sucking tube	XYGN-L293	1	
15	330402001	Oil back tube	YH-D	1	
16	330404001	Coupling	YL-A	1	
17	330403001	Oil sucking filter	YG-C	1	
18	330201014G	Gear pump	CBK-F242-G	1	3.5KW


Annex 4, Pneumatic scheme and parts list




POS.	Code	Description	Specification	Qty
1	321004006	AFC Air filter combination	AFC2000	1
2	310102015	Quick pneumatic connector	KLC8-02	3
2	310302002	Air hose connector (replace 310102015 since 2024.9)	TKN-PH8-02	3
3	123010101	Pneumatic hose	D6	1
4	310201002	Silencer	SLM02 R1/4 (M12)	1
5	310401001	Pneumatic solenoid valve	3V210-08DC24V	1
6	310101024	Pneumatic straight connector	KLC6-02	1
7	123010101	Pneumatic hose	D=6 20	1
8	310101024	Pneumatic straight connector	KLC6-01	4
9	310201003	Silencer	SLM01 R1/8 (M8)	4
10	310501005	Pneumatic cylinder	CQ2B32*30	4
11	310103005	Three way pneumatic connector	KLE-6	3

Annex 5, Mechanically exploded drawings and parts list
S-48L



Pos.	Code	Description	Specification	Qty
1	615025046	B platform assembly (48L)	6604V2S-A4B	1
2	615025045	A platform assembly (48L)	6604V2S-A4	1
3	615025041	Ramp assembly	6604V2-A9	2
4	615025036	Mechanical lock assembly	6604V2-A5B	2
5	615025037	Start-up assembly	6604V2-A6	2
6	615025033	Support arm assembly	6604V2-A3	2
7	615025032	Base plate b assembly	6604V2-A2	2
8	615025031	Base plate A assembly	6604V2-A1	2
9	410254483	Oil hose protective cover A	6604V2-A13	1
10	410254493	Oil hose protective cover B	6604V2-A14	1
11	410254503	Oil hose protective cover C	6604V2-A15	1
12	410254513	Oil hose protective cover D	6604V2-A16	1
13	202301008	Cross socket cap head tapping screw	ST4.8*35	20
14	121010103	Plastic expansion tube	M10*40	20




Pos.	Code	Description	Specification	Qty
1	615025048	B platform assembly (50L)	6604V2S-A4B	1
2	615025047	A platform assembly (50L)	6604V2S-A4	1
3	615025041	Ramp assembly	6604V2-A9	2
4	615025036	Mechanical lock assembly	6604V2-A5B	2
5	615025037	Start-up assembly	6604V2-A6	2
6	615025033	Support arm assembly	6604V2-A3	2
7	615025032	Base plate b assembly	6604V2-A2	2
8	615025031	Base plate A assembly	6604V2-A1	2
9	410254483	Oil hose protective cover A	6604V2-A13	1
10	410254493	Oil hose protective cover B	6604V2-A14	1
11	410254503	Oil hose protective cover C	6604V2-A15	1
12	410254513	Oil hose protective cover D	6604V2-A16	1
13	202301008	Cross socket cap head tapping screw	ST4.8*35	20
14	121010103	Plastic expansion tube	M10*40	20




Pos.	Code	Description	Specification	Qty
1	614901343	B platform assembly (48L)	6604BV2-A4B-B1	1
2	614901342	A platform assembly (48L)	6604BV2-A4-B1	1
3	615025041	Ramp assembly	6604V2-A9	2
4	615025036	Mechanical lock assembly	6604V2-A5B	2
5	615025037	Start-up assembly	6604V2-A6	2
6	615025033	Support arm assembly	6604V2-A3	2
7	615025032	Base plate b assembly	6604V2-A2	2
8	615025031	Base plate A assembly	6604V2-A1	2
9	410254483	Oil hose protective cover A	6604V2-A13	1
10	410254493	Oil hose protective cover B	6604V2-A14	1
11	410254503	Oil hose protective cover C	6604V2-A15	1
12	410254513	Oil hose protective cover D	6604V2-A16	1
13	202301008	Cross socket cap head tapping screw	ST4.8*35	20
14	121010103	Plastic expansion tube	M10*40	20




Pos.	Code	Description	Specification	Qty
1	615025050	B platform assembly (50L)	6604V2-A4B	1
2	615025049	A platform assembly (50L)	6604V2-A4	1
3	615025041	Ramp assembly	6604V2-A9	2
4	615025036	Mechanical lock assembly	6604V2-A5B	2
5	615025037	Start-up assembly	6604V2-A6	2
6	615025033	Support arm assembly	6604V2-A3	2
7	615025033	Support arm assembly	6604V2-A3	2
8	615025032	Base plate b assembly	6604V2-A2	2
9	410254483	Oil hose protective cover A	6604V2-A13	1
10	410254493	Oil hose protective cover B	6604V2-A14	1
11	410254503	Oil hose protective cover C	6604V2-A15	1
12	410254513	Oil hose protective cover D	6604V2-A16	1
13	202301008	Cross socket cap head tapping screw	ST4.8*35	20
14	121010103	Plastic expansion tube	M10*40	20



POS.	Code	Description	Specification	Qty
1	612019504	Shaft of the support holder	65012-A1-B5	2
2	614025056	Base A	6604V2-A1-B1	1
3	410254273	Bracket for limit switch (no this part for version with auto-bleeding cylinders)	6604V2-A1-B2	1
4	410250013	Plate for down limit switch	6604V2-A1-B3	1
5	320301003	Limit switch (no this part for version with auto-bleeding cylinders))	D4MC-5020	1
6	203101009	Hex nut M16	M16-GB6170	4
7	201201005	Expansion bolt	M16X120	4
8	202205002	Hex socket flat head tapping screw	M16X50-GB77	4
9	202101002	Cross socket cap head screw	M3X15-GB818	2
10	202109027	Hex socket cylinder head screw (no this part for version with auto-bleeding cylinders))	M8X12_GB70_1	2
11	202109027	Hex socket cylinder head screw	M8X12_GB70_1	1
12	202110004	Hex socket cap head screw	M8X12_GB70_2	2
13	208106002	Pressed oil cup M8	M8YP_GB7940_4	2
14	320302002	Proximity switch	PL-05P	1




POS.	Code	Description	Specification	Qty
1	614025058	Large base frame	6604V2-A2-B1	1
2	410253550	Pad plate for slider	6604V2-A2-B2	2
3	410253683B	Pressure plate for Base B	6604V2-A2-B3	2
4	410255153	Anti-roll plate for Base B	6604V2-A2-B4	2
5	201201005	Expansion bolt	M16X120	4
6	202205002	Hex socket flat head tapping screw	M16X50-GB77	6
7	203101009	Hex nut	M16_GB6170	6
8	202101029	Cross socket cap head screw	M6X12-GB818	4




POS.	Code	Description	Specification	Qty
1	205101052	Bearing	2530-SF-2X	4
2	205101060	Bearing	4050-SF-2X	2
3	420270070	Oil hose protective sheath	6435B-A3-B27	2
4	420210060B	Padding block	6603B-A5-B6	2
5	614025059B	Outside support arm	6604V2-A3-B1	1
6	614025060	Inside support arm	6604V2-A3-B2	1
7	410252281	Mid shaft of support bracket	6604V2-A3-B3	1
8	410250061	Rotor wheel pad	6604V2-A3-B4	2
9	410252321	DOWN cylinder shaft	6604V2-A3-B6	1
10	410254631	Clip	6604V2-A3-B8	2
11	420260020B	Platform slider	6605B-A6-B1-C2	2
12	420260030B	Base slider	6605B-A6-B2-C2	2
13	208101036	Clip	D20	1
14	206101008	Post pin	D10X30-GB119_2	4
15	204101014	Flat washer C	D27-GB95	2

POS.	Code	Description	Specification	Qty
16	204301010	Circlip	D28-GB894_2	2
17	204101015	Flat washer C	D30-GB95	6
18	204301011	Circlip	D30-GB894_2	2
19	204301014	Circlip	D40-GB894_2	2
20	202110007	Hex socket button head screw	M10X20-GB70_2	8
21	203103018	Hex locking nut	M24X3-GB6172_2	2
22	202109020	Hex socket cylinder head screw	M6X15-GB70_1	2
23	202101027	Cross socket cap head screw	M6X8-GB818	3
24	208106002	Pressed oil cup M8	M8YP-JB9740_4	2



POS.	Code	Description	Specification	Qty
1	205101053	Bearing	2840-SF-2X	1
2	205101034	Bearing	4030-SF-2X	2
3	420210020	Hex socket button head screw	6603B-A3-B9	2
4	410252381B	Upside shaft of the assisting cylinder	6604V2-A5-B4	1
5	410252391B	Downside shaft of the assisting cylinder	6604V2-A5-B5	1


POS.	Code	Description	Specification	Qty
6	410901931	Adjustable washer	6604V2-A5-B6	6
7	614901929	Mechanical locking ratchet	6604V2-A5-B7	1
8	410912332	Holder for the Micro switch	6604V2-A5-B8	1
9	614025070	Oil cylinder sheath	6604V2-A5B-B2	1
10	320307032	Micro switch	CMV10041C2	1
11	310501005	Air cylinder	CQ2B32X30D	2
12	204301010	Circlip	D28-GB894_2	2
13	204301014	Circlip	D40-GB894_2	2
14	310101024	Pneumatic straight connector	KLC6-01	2
15	202101002	Cross socket cap head screw	M3X15-GB818	2
16	202109006	Hex socket cylinder head screw	M4X8-GB70_1	4
17	202101033	Cross socket cap head screw	M6X20-GB818	8
18	208106001	Oil cup	M8X1-JB9740_1	1
19	320505041	Fast connecting terminal	PCT-223-2	1
20	310201003	Silencer	SLM01-R1-8	2
21	625000025	Assisting cylinder	YG75-85-45-595	1



POS.	Code	Description	Specification	Qty
1	410250211	Ramp shaft	6604V2-A4-B12	1
2	614025055B	Ramp	6604V2-A9-B1	1
3	410250161	Ramp wheel shaft of the JACK	6604V2-A9-B2	1
4	204301002	Circlip	D12_GB894_2	2


POS.	Code	Description	Specification	Qty
5	204301012	Circlip	D15_GB894_1	2
6	420180010	Small wheel	MR30-A22-B5	2

EE-6604S-48L




S/N	Code	Description	Specification	Qty
1	612019504	Shaft of the support holder	65012-A1-B5	2
2	614025066B	Small drive-on ramp	6604V2-A4-B10	1
3	410250211	Ramp shaft	6604V2-A4-B12	1
4	614025080	Platform ramp	6604V2-A4-B14	1
5	614025078	Platform A (welded assembly)	6604V2S-A4-B1	1
	614025079	Platform B (welded assembly)	6604V2S-A4B-B1	1
6	420260010	Adjustable nylon slider	6605-A1-B8	4
7	420260040	Limitation block	6605B-A21	2
8	204301002	Circlip	D12-GBT894_2	2
9	202109044	Hex socket cylinder head screw	M10X35-GB70	2
10	202109050	Hex socket cylinder head screw	M12X20-GB70	4
11	203101012	Hex nut M20	M20-GB6170	4
12	202205005	Hex socket flat head locking screw	M20X140_GB77	4
13	202110004	Hex socket cap head screw	M8X12_GB70_2	2
14	208106002	Pressed oil cup M8	M8YP_GB7940_4	2

EE-6604S-50L




S/N	Code	Description	Specification	Qty
1	612019504	Shaft of the support holder	65012-A1-B5	2
2	614025063	Box	6604V2-A4-B3	1
3	614025066	Small drive-on ramp	6604V2-A4-B10	1
4	410250211	Ramp shaft	6604V2-A4-B12	1
5	614025078	Platform A (welded assembly)	6604V2S-A4-B1	1
	614025079	Platform B (welded assembly)	6604V2S-A4B-B1	1
6	420260010	Adjustable nylon slider	6605-A1-B8	4
7	420260040	Limitation block	6605B-A21	2
8	204301002	Circlip	D12-GBT894_2	2
9	202109044	Hex socket cylinder head screw	M10X35-GB70	2
10	202109050	Hex socket cylinder head screw	M12X20_GB70	4
11	203101012	Hex nut M20	M20-GB6170	4
12	202205005	Hex socket flat head locking screw	M20X140_GB77	4
13	202110004	Hex socket cap head screw	M8X12_GB70_2	2
14	208106002	Pressed oil cup M8	M8YP_GB7940_4	2



S/N	Code	Description	Specification	Qty
1	420040020	Protective ring D20	6254E-A22	1
2	420270100B	Ball holder	6435B-A4-B20	4
3	420270110	Guiding ball	6435B-A4-B21	160
4	410274481	Pull spring	6435B-A4-B31	16
5	612019504	Shaft of the support holder	65012-A1-B5	2
6	410250221B	Bolt	6604B-A16	2
7	410250011	Washer	6604B-A1-B5	2
8	614901342	Platform A	6604BV2-A4-B1	1
9	420250010	Nylon sheath	6604V2-A4-B5	2
10	614025066B	Small drive-on ramp	6604V2-A4-B10	1
11	410250211	Ramp shaft	6604V2-A4-B12	1
12	614025067B	Slop plate	6604V2-A4-B13	1
13	614025080	Platform ramp	6604V2-A4-B14	1
14	410902033	Box(200mm)	6604V2-A4-B21	2
15	614901380	Fixed box (175mm)	6604V2-A4-B22	1
16	614901381	Box(70mm)	6604V2-A4-B23	1
17	420680084	Magnetic pad	6604V2-A4-B24	1
18	614901256	Slip plate	6604V2B-A4-B3	1
19	614901253	Mid platform	6604V2B-A4-B8	1
20	410901786	Decorative plate	6604V2B-A4-B20	2
21	420260040	Limitation block	6605B-A21	2
22	615026012	Steel rope locking device	6605B-A22	2
23	420260010	Adjustable nylon slider	6605B-A1-B8	4
24	204301002	Circlip	D12-GB894_1	2
25	206201004	Cotter pin	D3X45-GB91	2


S/N	Code	Description	Specification	Qty
26	202109044	Hex socket cylinder head screw	M10X35-GB70_1	2
27	202109050	Hex socket cylinder head screw	M12X20-GB70_1	4
28	203101012	Hex nut M20	M20-GB6170	8
29	202205005	Hex socket flat head locking screw	M20X140-GB77	4
30	203101004	Hex nut M6	M6-GB6170	16
31	202110003	Hex socket button head screw	M6X12-GB70_2	10
32	202109020	Hex socket cylinder head screw	M6X15-GB70_1	16
33	202110004	Hex socket cap head screw	M8X12-GB70_2	2
34	202109031	Hex socket cylinder head screw	M8X30-GB70_1	10
35	208106002	Pressed oil cup M8	M8YP-JB9740_4	2

48L-Platform B


S/N	Code	Description	Specification	Qty
1	420270100B	Ball holder	6435B-A4-B20	4
2	420270110	Guiding ball	6435B-A4-B21	160
3	410274481	Pull spring	6435B-A4-B31	16
4	612019504	Shaft of the support holder	65012-A1-B5	2
5	410250221B	Bolt	6604B-A16	2
6	410250011	Washer	6604B-A1-B5	2
7	614901343	Platform B	6604BV2-A4B-B1	1
8	420250010	Nylon sheath	6604V2-A4-B5	2
9	614025066B	Small drive-on ramp	6604V2-A4-B10	1
10	410250211	Ramp shaft	6604V2-A4-B12	1
11	614025067B	Slop plate	6604V2-A4-B13	1
12	614025080	Platform ramp	6604V2-A4-B14	1


S/N	Code	Description	Specification	Qty
13	410902033	Box(200mm)	6604V2-A4-B21	2
14	614901380	Fixed box (175mm)	6604V2-A4-B22	1
15	614901381	Box(70mm)	6604V2-A4-B23	1
16	420680084	Magnetic pad	6604V2-A4-B24	1
17	614901256	Slip plate	6604V2B-A4-B3	1
18	614901253	Mid platform	6604V2B-A4-B8	1
19	410901786	Decorative plate	6604V2B-A4-B20	2
20	420260010	Adjustable nylon slider	6605-A1-B8	4
21	420260040	Limitation block	6605B-A21	2
22	204301002	Circlip	D12-GB894_1	2
23	206201004	Cotter pin	D3X45-GB91	2
24	202109044	Hex socket cylinder head screw	M10X35-GB70_1	2
25	202109050	Hex socket cylinder head screw	M12X20-GB70_1	4
26	203101012	Hex nut M20	M20-GB6170	8
27	202205005	Hex socket flat head locking screw	M20X140-GB77	4
28	203101004	Hex nut M6	M6-GB6170	16
29	202110003	Hex socket button head screw	M6X12-GB70_2	10
30	202109020	Hex socket cylinder head screw	M6X15-GB70_1	16
31	202110004	Hex socket cap head screw	M8X12-GB70_2	2
32	202109031	Hex socket cylinder head screw	M8X30-GB70_1	10
33	208106002	Pressed oil cup M8	M8YP-JB9740_4	2

50L-Platform A



S/N	Code	Description	Specification	Qty
1	420040020	Protective ring D20	6254E-A22	1
2	420270100B	Ball holder	6435B-A4-B20	4
3	420270110	Guiding ball	6435B-A4-B21	160
4	410274481	Pull spring	6435B-A4-B31	16
5	612019504	Shaft of the support holder	65012-A1-B5	2
6	410250221B	Bolt	6604B-A16	2
7	410250011	Washer	6604B-A1-B5	2
8	614901342	Platform A	6604BV2-A4-B1	1
9	614025063	Box	6604V2-A4-B3	1
10	420250010	Nylon sheath	6604V2-A4-B5	2
11	614025066B	Small drive-on ramp	6604V2-A4-B10	1
12	410250211	Ramp shaft	6604V2-A4-B12	1
13	614025067B	Slope plate	6604V2-A4-B13	1
14	410902033	Box(200mm)	6604V2-A4-B21	2
15	614901380	Fixed box (175mm)	6604V2-A4-B22	1
16	614901381	Box(70mm)	6604V2-A4-B23	1
17	420680084	Magnetic pad	6604V2-A4-B24	1
18	614901256	Slip plate	6604V2B-A4-B3	1
19	614901253	Mid platform	6604V2B-A4-B8	1
20	410901786	Decorative plate	6604V2B-A4-B20	2
21	420260040	Limitation block	6605B-A21	2
22	615026012	Steel rope locking device	6605B-A22	2
23	420260010	Adjustable nylon slider	6605B-A1-B8	4
24	204301002	Circlip	D12-GB894_1	2

S/N	Code	Description	Specification	Qty
25	206201004	Cotter pin	D3X45-GB91	2
26	202109044	Hex socket cylinder head screw	M10X35-GB70_1	2
27	202109050	Hex socket cylinder head screw	M12X20-GB70_1	4
28	203101012	Hex nut M20	M20-GB6170	8
29	202205005	Hex socket flat head locking screw	M20X140-GB77	4
30	203101004	Hex nut M6	M6-GB6170	16
31	202110003	Hex socket button head screw	M6X12-GB70_2	10
32	202109020	Hex socket cylinder head screw	M6X15-GB70_1	16
33	202110004	Hex socket cap head screw	M8X12-GB70_2	2
34	202109031	Hex socket cylinder head screw	M8X30-GB70_1	10
35	208106002	Pressed oil cup M8	M8YP-JB9740_4	2

50L-Platform B


S/N	Code	Description	Specification	Qty
1	420270100B	Ball holder	6435B-A4-B20	4
2	420270110	Guiding ball	6435B-A4-B21	160
3	410274481	Pull spring	6435B-A4-B31	16
4	612019504	Shaft of the support holder	65012-A1-B5	2
5	410250221B	Bolt	6604B-A16	2
6	410250011	Washer	6604B-A1-B5	2
7	614901343	Platform B	6604BV2-A4B-B1	1
8	614025063	Box	6604V2-A4-B3	1
9	420250010	Nylon sheath	6604V2-A4-B5	2
10	614025066B	Small drive-on ramp	6604V2-A4-B10	1

S/N	Code	Description	Specification	Qty
11	410250211	Ramp shaft	6604V2-A4-B12	1
12	614025067B	Slope plate	6604V2-A4-B13	1
13	410902033	Box(200mm)	6604V2-A4-B21	2
14	614901380	Fixed box (175mm)	6604V2-A4-B22	1
15	614901381	Box(70mm)	6604V2-A4-B23	1
16	420680084	Magnetic pad	6604V2-A4-B24	1
17	614901256	Slip plate	6604V2B-A4-B3	1
18	614901253	Mid platform	6604V2B-A4-B8	1
19	410901786	Decorative plate	6604V2B-A4-B20	2
20	420260010	Adjustable nylon slider	6605-A1-B8	4
21	420260040	Limitation block	6605B-A21	2
22	204301002	Circlip	D12-GB894_1	2
23	206201004	Cotter pin	D3X45-GB91	2
24	202109044	Hex socket cylinder head screw	M10X35-GB70_1	2
25	202109050	Hex socket cylinder head screw	M12X20-GB70_1	4
26	203101012	Hex nut M20	M20-GB6170	8
27	202205005	Hex socket flat head locking screw	M20X140-GB77	4
28	203101004	Hex nut M6	M6-GB6170	16
29	202110003	Hex socket button head screw	M6X12-GB70_2	10
30	202109020	Hex socket cylinder head screw	M6X15-GB70_1	16
31	202110004	Hex socket cap head screw	M8X12-GB70_2	2
32	202109031	Hex socket cylinder head screw	M8X30-GB70_1	10
33	208106002	Pressed oil cup M8	M8YP-JB9740_4	2