


**Model No. EE-C9M**

Two Post Lift,  
Manual Release  
Lifting Capacity 3500KG

**Installation, Operation  
and Parts Manual**



**EAE**



*Distributed by*

*Please read this entire manual carefully and completely before installation or operation of the lift.*

**DATE: 10/12/2024**

**[www.eae-ae.com](http://www.eae-ae.com)**

## IMPORTANT NOTES

Before start up, connecting and operating EAE products, it is absolutely essential that the operating instructions/owner's manual, and in particular the safety instructions are studied carefully. By doing so you can eliminate any uncertainties in handling EAE products and thus associated safety risks up front; something which is in the interest of your own safety and will ultimately help avoid damage to the device. When an EAE product is handed over to another person, not only the operating instructions but also the safety instructions and information on its designated use must be handed over to the person.

By using the product you agree the following conditions:

### **Copy right**

The enclosed instructions are the property of EAE or its supplier, and are protected against duplication and reproduction by copyright laws, international agreements, and other domestic legislation. The reproduction or disclosure of instructions or an extract thereof is prohibited and offenders are liable to prosecution; EAE reserves the right to initiate criminal proceedings and asserts claims for damages in the event of infringements.

### **Warranty**

The use of non-approved hardware will result in a modification of our products and thus to the exclusion of any liability or warranty, even if such hardware has been removed again in the interim.

It is not permissible to make any changes to our products and these are not only to be used together with genuine accessories and genuine replacement parts. Otherwise any warranty claims will be invalid.

### **Liability**

The liability of EAE is limited to the amount that the customer has actually paid for this product. This exclusion of liability does not apply to damages caused through willful misconduct or gross negligence on the part of EAE.

**All information in this manual is believed to be correct at time of publication.**

**EAE reserves the right to amend and alter technical data and composition without prior notice.**

**Please confirm at time of ordering.**

<b>IMPORTANT NOTES.....</b>	<b>2</b>
<b>SAFETY NOTES.....</b>	<b>4</b>
1.1 Operation of lifting platforms .....	4
1.2 Checking of the lifting platforms.....	4
1.3 Important safety notices .....	5
1.4 Warning labels .....	6
1.5 Potential safety risks .....	7
1.6 Noise level .....	7
<b>PACKING, STORAGE AND TRANSPORTATION .....</b>	<b>8</b>
2.1 The lift was dismantled into the following 3 parts for transportation.....	8
2.2 Storage.....	8
2.3 Opening the packs.....	8
<b>PRODUCTS DESCRIPTIONS.....</b>	<b>9</b>
3.1 General descriptions.....	9
3.2 Construction of the lift .....	9
3.3 Technical data .....	9
3.4 Dimensions .....	10
3.5 Safety devices descriptions.....	12
<b>INSTALLATION INSTRUCTIONS.....</b>	<b>13</b>
4.1 Preparations before installation .....	13
4.2 Installation attentions.....	14
4.3 General installation steps.....	14
4.4 Items to be checked after installation.....	16
<b>OPERATION INSTRUCTIONS.....</b>	<b>26</b>
5.1 Precautions.....	26
5.2 Operation instructions .....	26
<b>TROUBLE SHOOTING .....</b>	<b>28</b>
<b>INSPECTION AND MAINTENANCE .....</b>	<b>29</b>
Annex 1, Floor plan .....	31
Annex 2, Electrical schemes and parts list .....	32
Annex 3, Hydraulic schemes and parts list.....	33
Annex 4, Mechanical exploded drawings and parts list.....	36

# SAFETY NOTES

## 1.1 Operation of lifting platforms

This lift is specially designed for lifting motor vehicles. Users are not allowed to use it for any other purposes. The applicable national regulations, laws and directives must be observed.

Only users aged 18 or above who have been instructed on how to operate the lifting platform and have proven their ability to do so to the owner are to be entrusted with unsupervised operation of lifting platforms. The task of operating the lifting platforms must be granted in writing.

Before loading a vehicle onto the lift, users should study the original operation instructions and familiarize themselves with the operating procedures in several trial runs.

**Lift vehicle within the rated load. Don't attempt to raise vehicles with excessive weight.**

## 1.2 Checking of the lifting platforms

Checks are to be based on the following directives and regulations:

- Basic principles for testing lifting platforms
- The basic health and safety requirement
- The applicable accident prevention regulations

The checks are to be organized by the user of the lifting platform. The user is responsible for appointing an expert or qualified person to perform checking. It must be ensure that the person chosen satisfies the requirements.

The user bears special responsibility if employees of the company are appointed as experts or qualified persons.

### 1.2.1 Scope of checking

Regular checking essentially involves performing a visual inspection and a functional test. This includes checking the condition of the components and equipment, checking that the safety systems are complete and functioning properly and that the inspection log book is completely filled in. The scope of exceptional checking depends on the nature and extent of any structural modification or repair work.

### 1.2.2 Regular checking

After initial commissioning, lifting platforms are to be checked by a qualified person at intervals of not longer than one year.

**A qualified person** is somebody with the training and experience required to possess sufficient knowledge of lifting platforms and who is sufficiently familiar with the pertinent national regulations, accident prevention regulations and generally acknowledged rules of engineering to be able to assess the safe operating condition of lifting platforms.

### 1.2.3 Exceptional checking

Lifting platforms with a lift height of more than 2 meters and lifting platforms intended for use with people standing under the load bearing elements of the load are to be checked by an expert prior or reuse following structural modifications and major repairs to load bearing components.

**An expert** is somebody with the training and experience required to possess specialist knowledge of lifting platforms and who is sufficiently familiar with the pertinent national work safety regulations, accident prevention regulations and generally acknowledged rules of engineering to be able to check and give an expert option on lifting platforms.

### 1.3 Important safety notices

- 1.3.1 The lift is designed for indoor installation only. Do not expose the lift to rain, snow or excessive moisture. Do not use the lift near explosives or open areas containing inflammable liquids.
- 1.3.2 Only use this lift on a surface that is stable and capable of sustaining the load. Do not install the lift on any asphalt surface.
- 1.3.3 Read and understand all safety warnings before operating the lift.
- 1.3.4 Do not leave the controls while the lift is still in motion.
- 1.3.5 Keep hands and feet away from any moving parts. Keep feet clear of the lift when lowering.
- 1.3.6 Only these properly trained personnel can operate the lift.
- 1.3.7 Do not wear unfit clothes such as large clothes with flounces, tires, etc., which could be caught by moving parts of the lift.
- 1.3.8 To prevent evitable incidents, surrounding areas of the lift must be tidy and with nothing unconcerned.
- 1.3.9 The lift is simply designed to lift the entire body of vehicles, with its maximum weight within the lifting capacity.
- 1.3.10 Always insure the safety locks are engaged before any attempt to work near or under the vehicle. Never remove safety related components from the lift. Do not use if safety related components are damaged or missing.
- 1.3.11 Do not rock the vehicle while on the lift or remove any heavy component from vehicle that may cause excessive weight shift.
- 1.3.12 Check at any time the parts of the lift to ensure the agility of moving parts and the performance of synchronization. Ensure regular maintenance and if anything abnormal occurs, stop using the lift immediately and contact our dealers for help.
- 1.3.13 Lower the lift to its lowest position and do remember to cut off the power source when service finishes.
- 1.3.14 Do not modify any parts of the lift without manufacturer's advice.
- 1.3.15 If the lift is going to be left unused for a long time, users are required to:
- Disconnect the power;
  - Empty the oil tank;
  - Lubricate the moving parts with hydraulic oil.















**WARNING:** The warnings, cautions and instructions discussed in this instruction manual cannot cover all possible conditions and situations that may occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.

## 1.4 Warning labels

All safety warning labels are clearly depicted on the lift to ensure that the operator is aware of and avoid the dangers of using the lift in an incorrect manner. The labels must be kept clean and they have to be replaced if detached or damaged. Please read carefully the meaning of each label and memories them for future operation.

SAFETY ADVICE

54011124

<b>CAUTION</b>	
	<p>ONLY trained and authorized persons are permitted to operate the lift .</p>
<p>Read the complete instructions for operating and trouble shooting.</p>	
	<p>Always keep the lift area free of obstructions before raising or lowering.</p>
<p>Position pads under pick-up points recommended by the vehicle manufacturer.</p>	
	<p>Observe the load throughout the motion of the lift .</p>
<p>Engage the locking mechanism before working under the vehicle.</p>	
	<p>Wear proper Personal Protection Equipment before working under lifted vehicles.</p>
<p>Carry out maintenance regularly as required in the manual.</p>	
<b>WARNING</b>	
	<p>Check support for secure contact with vehicle and check the engagement of arm locks after a short rise less than 300mm.</p>
<p>Always use safety stands when heavy vehicle components are removed or installed.</p>	
	<p>Do not climb or travel on the raised arms or vehicles.</p>
<p>Avoid excessive rocking of vehicle on lift .</p>	
<b>DANGER</b>	
	<p>Do not stand under the load during lifting and lowering movement.</p>
<p>Do not interrupt or modify safety and protective device.</p>	

The instructions , cautions and warnings written above as well as in the in Manual cannot cover all possible conditions and situations that may occur. The Common sense for safety must be always in the mind of the operator. For damages caused through willful misconduct or gross negligence, the manufacturer or distributors are excluded of liability.

## 1.5 Potential safety risks

### 1.5.1 Mains voltage



Insulation damage and other faults may result in accessible components being live

Safety measures:

- Only ever use the power cord provided or a tested power cord.
- Replace wires with damaged insulation.
- Do not open the operating unit.

### 1.5.2 Risk of injury, danger of crushing

In the event of excessive vehicle weight, incorrect mounting of the vehicle or on removing heavy object, there is a risk of the vehicle falling off or tipping up.

Safety measures:

- The lift is only ever to be employed for the intended purpose.
- Carefully study and heed all the information given in section 1.4.
- Observe the warning notices for operation.

## 1.6 Noise level

Noise emitted during operating the lift should be less than 70dB (A). For your health consideration, it is suggested to place a noise detector in your working area.

## PACKING, STORAGE AND TRANSPORTATION

Packing, lifting, handling, transporting operations must be performed only by experienced personnel with appropriate knowledge of the lift and after reading this manual.

### 2.1 The lift was dismantled into the following 3 parts for transportation

Name	Packed by	Dimension(mm)	Weight(kg)	Quantity
Lift	Steel brackets	2865*570*770	556	1
Extending post	Bubble film	1300*380*250	66	1
Power unit	Carton	850*250*350	24	1

### 2.2 Storage

The packs must be kept in a covered and protected area in a temperature range of -10°C to +40°C. They must not be exposed to direct sunlight, rain or water.

#### Stacking the packs

We advise against stacking because the packs are not designed for this type of storage. The narrow base, heavy weight and large size of the packs make stacking difficult and potentially dangerous.

If stacking is unavoidable, use all appropriate precautions:

- Never stack to more than 2 meters in height.
- Never make stacks of single packs. Always stack pairs of packs in a cross pattern so that the base is bigger and the resulting stack is more stable. Once the stack is complete, restrain it using straps, ropes or other suitable methods.

A maximum of two packs can be stacked on lorries, in containers, and in railway wagons, on condition that the packs are strapped together and restrained to stop them falling.

### 2.3 Opening the packs

The packs can be lifted and transported only by using lift trucks. Never attempt to hoist or transport the unit using lifting slings.



When the lift is delivered make sure that it has not been damaged during transportation and that all the parts specified on the packing list are present.

Packs must be opened adopting all the precautions required to avoid injury to persons (Keep at a safe distance when cutting the straps) or damage to parts of the machine (Be careful that no parts are dropped while you are opening the packing).

**Take special care with the hydraulic power unit and the cylinder.**



## PRODUCTS DESCRIPTIONS


### 3.1 General descriptions

This is chassis supporting vehicle lift for road vehicles.

It is mainly composed by two posts, two carriages, four swing arms and a power and control unit.

It is driven by an electro-hydraulic system. The gear pump delivers hydraulic oil to oil cylinders and pushes upwards its piston. The cylinder piston drives to raise the carriage and swing arms. It is equipped with mechanical safety locking unit which ensures no risks of slipping off in case of hydraulic failure.

### 3.2 Construction of the lift




1. Overhead crossbeam
2. Extending post
3. Mechanical safety latch
4. Control unit
5. Hydraulic power unit
6. Lifting arm
7. Hydraulic cylinder
8. Post
9. Carriage

### 3.3 Technical data


Lifting capacity	3500kg
Max. height of the pick-up adapter	1900mm(locking device disengaged)
Min. height of the pick-up adapter(standard arm)	95mm
Min. height of the pick-up adapter(low-profile arm, optional)	85mm
Full rise time (with rated load,2.2kW 1Ph/3Ph)	Approx.55s
Full descent time (with rated load)	45-55s
Oil tank volume	10L

### 3.4 Dimensions


Dimension scheme with two 3-stage arms and two 2-stage arms (Standard arms)



### Dimension scheme with four 3-stage low-profile arms (Optional arms)



### 3.5 Safety devices descriptions



Pos.	Description	Function
1	Roof protective limit switch	Stop rising in case the overhead bar is touched.
2	Max rise limit switch	Stop rising at max height.
3	Mechanical safety locking unit	Catch the carriages in case of hydraulic failure.
4	Arm lock	Ensure the lifting arms are locked and avoid being swinging during lifting process.

# INSTALLATION INSTRUCTIONS

## 4.1 Preparations before installation

### 4.1.1 Space requirements.

The lift is designed for indoor installation only. Do not expose the lift to rain, snow or excessive moisture. Do not use the lift near explosives or open areas containing inflammable liquids.

Refer to 3.4 for the dimensions of the lift. There must be sufficient space for driving and lifting vehicles and enough safety distance shall be reserved according to the regulations of the local authorities. It is advised to reserve a clearance of at least 1 meter between the lift and fixed elements (e.g. wall) in all lifting positions.

### 4.1.2 Foundations and connections

The user must have the following work performed before erecting the lift.

Construction of the foundation following consultation with the manufacturer's customer service or an authorized service agent. Routing of the wiring to the installation location. **The user must provide fuse protection for the connection. Electrical system connection must be done by licensed technicians.** Requirements for power supply cable of the installation site: at least 2.5mm<sup>2</sup> wire core for 3Ph power and 4.0mm<sup>2</sup> wire core for 1Ph power.

Refer also to the corresponding information on the name plate and in the operation instructions.

Before doing electrical connection, make sure the lift is electrically adapt to the local power supply.

### 4.1.3 Foundations preparations

Refer to Annex 1 for footing.

**To ensure stability and safety under load, the lift shall be installed with the base frame being in direct and firm contact with the concrete foundation. Don't attempt to fix the base frame directly onto floor with ceramic and other decorated surfaces otherwise you put the lift into a very dangerous situation.**

C25/C30 concrete foundation with a minimum thickness of 200mm (Continuous footing).

Surface: Horizontal and even (Gradients max. 0.5 %)

Newly built concrete ground must be older than 20days.

### 4.1.4 Tools and equipment needed for installation

Tool name	Specification	Quantity
Electrical drill	D18 drill bit	1
Open spanner	D17-19mm	2
Adjustable spanner	Bigger than D30	1
Cross socket screw driver	PH2	1
Quick spanner handle adapter/ Ratchet	REB-310	1
Socket spanner	D24	1
Levelling device	Accuracy: 1mm	1
Hammer	10 pounds	1
Truck lift	Capacity, 1000kg	1
Lifting string	Capacity, 1000kg	2
Torque spanner	MD400	1

## 4.2 Installation attentions

- 4.2.1 Tighten all hydraulic and electrical connections.
- 4.2.2 Tighten all screws, nuts and bolts.
- 4.2.3 Do not place any vehicle on the lift in the case of trial running.


## 4.3 General installation steps

**ONLY TRAINED AND QUALIFIED INSTALLERS CAN PERFORM LIFT INSTALLATION DUTIES.**

**Step 1: Remove the packaging and take out the accessories attached.**

*Attention : The packs must be opened adopting all the precautions required to avoid injury to persons (Keep at a safe distance when cutting the straps) or damage to parts of the machine (Be careful that no parts are dropped while you are opening the packaging).*

**Use proper means (Put something supporting under the post or suspend the post by a crane) to suspend the post, unscrew and remove the bolts fixed on the iron rack.**




- 1. Hex bolt
- 2. Iron rack

*Attention : Please pay special attention not to let the post fall down for it may cause casualty or bring damages to the accessories fixed in the post.*

**Step 2: Assemble the two posts.**

Connect extending post onto main posts using screw M14\*30.




- 1. Hex nut M14
- 2. Flat washer M 14
- 3. Spring washer M14
- 4. Hex head full swivel screw M14\*30
- 5. Extending post

## Step 3: Fix the standing position for the two posts. (See Annex 1, Floor plan)

1. Identify on which post the power unit will be mounted.
2. Draw an outline of the base plate on the installation ground with chalk and ascertain the position for the two posts. (Refer to the fig. in step 4)
3. Refer to 3.4 dimensions of the lift, make the posts face to each other and use proper means to erect the posts.

## Step 4: Erect and secure the post.



1. Check and align the position of the two base plates again.



2. Use suitable means to raise the lifting carriage to the first latching position. All the mounting holes on the base plate are then accessible. Make sure the locking pawl is engaged.
3. Drill the mounting holes. Remove the drilling dust from the hole.
4. Use a spirit level to check the vertical alignment of the posts. Place equalizing plates under the base plates when it necessary to assure the verticality of the post.

**Caution:** Don't add more than 1 equalizing plate under one anchor position of the base plate, otherwise there could be risks of slanting due to uneven load transfer to the foundation.


5. Tighten the nuts. **Torque: 80-100Nm.**



A. Nut

B. Expansion anchoring bolt

C. Equalizing plate




Anchoring bolt	A1 (Foundation thickness )	A2 (Drilling depth)	A3 (Anchoring depth)	B	C
M18x160	≥200mm	130mm	105mm	240mm	≤55mm

## Step 5: Connect and install the crossbeam.


Firstly, assemble beam 1 with beam 2 using screw M14\*30.

**CAUTION!** It is important to check and assure the entire beam is straightly connected with no twisting.

To get rid of the twisting, you can adjust the screws (Pos.4) that tighten beam 1 and beam 2.



Then, make one end of the roof protective rod (Pos.8) go through the hole of the holder attached under the beam and fix the other end of the rod with the beam using hex socket cylinder head screw M6x30 (Pos.6)



1. Hex nut M14
2. Flat washer M14
3. Spring washer M14
4. Hex head full swivel screw M14x30
5. Crossbeam
6. Hex socket cylinder head screw M6x30
7. Hex nut M6
8. Protective rod
9. Extending post





### Step 6: Install the mechanical safety locking unit.

#### 6.1 Assemble the mechanical locking unit.

locking device on power side post

locking device on the secondary post



1. Circlip
2. Washer
3. Spring 1
4. Spring 2
5. Shaft
6. Release handle
7. Hook
8. Nylon spacer
9. Release plate
10. Rope installation fitting

#### 6.2 Route and fix the release rope for mechanical locking assembly.


There are 2 pairs of holes reserved on the top side of column and 4 pairs of holes reserved on the holder (Pos.2) assembled with rope-guiding pulley.

Aligned the bottom pair of holes of the holder with the pair of holes marked with "✓" in following figure and fasten the holder using the screws and nuts (Pos.1 and Pos.3).

**CAUTION!** The holder (Pos.2) shall be positioned along the inside surface of the column.

**CAUTION!** Install the other holder symmetrically at the same position of the other column.


**CAUTION!** Don't install the holder using the other pair of holes marked with "×".




1. Hex socket cylinder head screw M8X25
2. Holder for guiding pulley
3. Hex locking nut M8
4. Release steel rope

After the rope has been correctly routed through the pulleys, fix both ends of the rope onto the fittings reserved on both locking units.

**Attention:** The holder of the pulley has to be dismantled from the column before make the release rope go through the pulley nearby the locking unit.




**Attention:** Tighten the nuts showing in the below scheme.



### 6.3 Install the switch.


Install the holder (Pos.4) onto the post and fix the switch (Pos.1).

Adjust the position of the switch, making it can be activated when the release handle has been pushed down maximally.




**Step 7: Connect the synchronization steel rope.**

1. Route and fix according to the following scheme.
2. Before attempting to route the ropes, raise the lifting carriage at both sides to the first latching position making sure that the mechanical safety locking units in each post are fully engaged.
3. Adjust and make the ropes at both sides be under the same tension which could be judged by the sound emitted during lifting process.
4. Grease with No.1 lithium grease.



**Step 8: Install the power and control unit.**

Mount and tighten the power unit onto the extending post. Install the control box onto main post.




- 1. Cross socket cap head screw M5x8
- 2. Control box
- 3. Hex head flange screw M8x30
- 4. Anti-vibration pad
- 5. Hex flange nut M8
- 6. Hydraulic power unit

### Step 9: Connect the hydraulic hoses

It must be taken adequate care that all connectors shall be tightened against leakage.

Don't let any solid substance go into the hydraulic line. Severe leakage will occur if the hose connectors are not tightened.

**Torque: 25-30Nm.**



- 1. Oil hose A
- 2. Hydraulic cylinder
- 3. Three way connector
- 4. Oil hose B
- 5. Oil hose C
- 6. Composite connector
- 7. Power unit

## Step 10: Make the electrical connection.

**ONLY** qualified electricians are permitted doing the electrical connection.


Read the name plate and check that the supply voltage is adapted to the voltage of the lift.

Read electrical connection diagram in Annex 2 for reference before doing the connection.

**Caution:** All electrical wires shall be properly secured against interference with the wire ropes.

1. Fix max height limit switch onto the inside surface of the power side post.


Connect the wires of the switch with the corresponding terminals reserved in the control box.



1. Cross socket flat head screw M5\*10

2. Max height limit switch

2. Fix roof protection limit switch onto the overhead crossbeam and connect its wire to the terminals reserved in the control box.



1. Limit switch

2. Hex socket screw M4x25


3. Wire for switch

3. Refer to the wire connection schemes and connect wires to the corresponding terminals in the control box.

## Step 11: Install lifting arms.

Install the lifting arms onto the carriages and ensure the arm lock can engage and release effectively.

**Attention:** *Install lifting arms and fenders ONLY after the complete assembly has been erected and anchored.*



## Step 12: Fill with hydraulic oil.

### ONLY CLEAN AND FRESH OIL ONLY

**Lift must be fully lowered before changing or adding hydraulic oil.**

Prepare 12 liters anti-abrasion hydraulic oil. Fill about 10 liters into the oil tank to run the lift up and down for 2 or 3 times after the electrical system is connected. Bleeding the hydraulic system and add more oil after running the lift for several cycles until the lift can rise to the maximum lifting height.

**Note:** It is suggested to use HM NO.46 hydraulic oil. When average temperature of the location is below 10°C, use HM NO.32 hydraulic oil.

Change the oil 6 months after initial use and once per year thereafter.

## Step 13: Trial running.

**The purpose for trial commissioning is to check whether the lift is ready for safe use.**

**The user shall get familiar with lift controls through raising and lowering the lift a few cycles before using it to lifting vehicles.**

### Bleeding the hydraulic system

Vent air remained the oil cylinder. Screw loose but don't remove the nut on top of the oil cylinder and slightly press the UP button until oil gets out. Screw the nut tight thereafter.



Vent air remained in the cylinder

After bleeding, fluid level in power unit reservoir may be down. Add more fluid if necessary to raise lift to full height. It is only necessary to add fluid to raise lift to full height.

### Check the mechanical safety locking system.

Check if mechanical locks can be well engaged and released in the lifting and lowering process.

Adjust the tension of the release rope when necessary.

### Check the synchronization of lifting carriages.

Adjust the nuts that fix the ropes at both sides, making them be under the same tension.

This could be judged by the sound emitted by the safety locking unit during lifting process.

### Check the hydraulic lines.


Raise and lower for several complete cycles and inspect if the hose connectors, cylinders and valves are well tightened without leakage.

Check the speed for rising and lowering, ensuring that the maximum permitted speeds are not exceeded.

***If the lift doesn't raise, the motor may turn in the wrong direction. In such event, interchange wires U, V in the connection box.***

## Step 14: Fix two protective covers.

Fix the covers (Pos.1, Pos.4) onto the posts.



1. Cover 1

2. Hex socket cylinder head screw M6x8


3. Main post

4. Cover 2

5. Hex socket cylinder head screw M6X10

6. Secondary post

## Step 15: Fix door-opening protection pads and pick-up pads.



1. Carriage

2. Door protection pad


3. Hex socket cylinder head screw M8X30

4. Plastic protective cover

5. Pick-up pad




**Step 16: Fix the protective column curtain.**



- 1.Hex nut M6
- 2.Class C flat washer M6
- 3.Hook
- 4. Column curtain.
- 5. Cross socket cap head screw M6x8

**Step 17: Install the height-extension adapter holder. (Optional)**



- 1. Height-extension adapter
- 2.Holder
- 3.Hex socket button head screw M8x12

#### 4.4 Items to be checked after installation

S/N	Check items	YES	NO
1	Screw torque of expansion bolts : 80-100Nm.	√	
2	Rising speed $\geq 20\text{mm/s}$ .	√	
3	Noise with load $\leq 70\text{dB(A)}$ .	√	
4	Grounding resistance: not bigger than $4\Omega$ .	√	
5	Height difference of the two carriages $\leq 5\text{mm}$ ;	√	
6	Mechanical catch unit is robust and synchronized when running with rated load.	√	
7	All control buttons works as “hold to run” .	√	
8	The limit switches work well.	√	
9	The grounding wire is connected.	√	
10	The carriage rises and lowers smoothly.	√	
11	There is no abnormal noise when run with load.	√	
12	There is no oil leakage when run with load.	√	
13	The expansion bolts, nuts or circlips are well secured or tightened.	√	
14	The max lifting height can be reached.	√	
15	All safety advices, name plate and logos are clear.	√	


## OPERATION INSTRUCTIONS

### 5.1 Precautions

- ONLY authorized persons are permitted in the lift area.
- Do not try to raise the vehicle with excessive length or width. Otherwise there is risk of vehicle falling from lift.
- Inspect the space above and below the load and the loading carrying devices. It shall be free of obstructions before operating.
- Before raising operation, run the lift without load for a complete cycle to ensure it is in good condition.
- Before lifting the vehicle and during all operations on the vehicle, make sure that it is properly stopped by the hand brake.
- Check the vehicle after raising a short distance to ensure that it is correctly and safely positioned.
- It is forbidden for people to stand in the field of motion during raising or lowering movement.
- The load carrying device shall be observed by the operator throughout the motion of the lift.
- Engage the safety locking mechanism before entering under the raised vehicle.
- Avoid excessive rocking of vehicle while on the lift
- Always use safety stands when moving or installing heavy components.
- Do not climb onto the load or load carrying device when they are raised.

## 5.2 Operation instructions

To avoid personal injury and property damage, permit only trained and qualified personnel to operate the lift. After reviewing these instructions, get familiar with lift controls by running the lift through a few cycles before loading vehicle on lift. Always lift the vehicle using all four adapters. Never raise just one end, one corner or one side of vehicle adapters.



Pos.	Descriptions	Function
1	Handle	Release the mechanical locking unit and control the descending movement
QS	Power switch	Turn on or off the power supply.
HL	Indicating light	Indicate if power is on.
SB1	UP button	Control the rising movement.
SB2	Safety lock button	Engage the mechanical safety lock

**Only one operator is allowed to work around the vehicle lift.**

**Always engage the safety locking mechanism before any operation on the lifted vehicle.**

**Do not make any operation on the lifted vehicle at a height under the first latching position (less than 500mm).**

**Never attempt to lower the lifted vehicle to the bottom when any of its wheel is removed unless you are assured that no damage will occur.**

### Raise

**Make sure vehicle is neither front nor rear heavy and center of balance should be midway between adapters and centered over the lift.**

**Warning: Always remember to check the engagement of all four swing arm locks and to check all four pick-up adapters for secure contact after a short rise less than 300mm. Otherwise, there could be risks of falling over.**

1. Park the vehicle between two posts.
2. Adjust the lifting arms until lifting adapters are under the pick-up positions of the vehicle and make sure the gravity of vehicle located over the center of four lifting arms.
3. Push the "UP" button until lifting adapters have touched the pick-up positions of vehicle.
4. Keep on raising the vehicle making its wheels have a bit clearance off the ground, stop raising and check again for secure contact.
5. Raise the vehicle to the expected height, push the "Safety lock button" to engage the mechanical safety locking unit. Check again the stability before doing maintenance or repair work underneath.

### Lower

**Pay careful attention that all personnel and objects are kept clear before lowering.**

1. Push the "UP" button to disengage the mechanical locking unit.
2. Push down the handle (Pos.1) to release mechanical locking unit completely, meanwhile the lifting device starts descending.
3. When the lift is fully lowered, position the lift arms and adapters to provide an unobstructed exit before removing vehicle from lift area.
4. Drive the vehicle away.

## TROUBLE SHOOTING

ATTENTION: If the trouble could not be fixed by yourself, please do not hesitate to contact us for help. We will offer our service at the earliest time we can. Troubles could be judged and solved much faster when more details or pictures could be provided.


TROUBLES	POSSIBLE CAUSES	SOLUTIONS
Abnormal noise	Abrasion exists on insider surface of the posts.	Grease the inside of the post.
	Trash in the post.	Clear the trash
Motor does not run and will not rise	Loose wire connection	Check and make a good connection.
	Blown motor.	Replace it.
	Damaged limit switch or its wire connection is loose.	Adjust or replace the limit switch.
Motor runs but will not raise	The motor run reversely.	Check the wire connection.
	Relief valve is not well screwed up or jammed.	Clean or make adjustment
	Damaged gear pump.	Replace it.
	Too low oil level.	Add oil.
	The hose connection is loose.	Tighten it.
	The cushion valve is not well screwed up or jammed.	Clean or make adjustment
Carriages go down slowly after being raised	The oil hose leaks.	Check or replace it.
	Untightened oil cylinder.	Replace the seal.
	The single way valve leaks.	Clean or replace it.
	Unloading valve fails to work well.	Clean or replace it.
	Slack steel rope	Check and adjust the tightness.
Raising too slow	Jammed oil filter	Clean or replace it.
	Too low oil level.	Add oil.
	The relief valve is not adjusted to the right position.	Make adjustment.
	Too hot hydraulic oil ( above 45° ) .	Change the oil.
	Abraded seal of the cylinder	Replace the seal.
	Inside surface of the posts is not well greased.	Add grease.
Lowering too slow	Jammed throttle valve	Clean or replace.
	Dirty hydraulic oil	Change the oil.
	Jammed anti-surge valve	Clean it.
	Jammed oil hose	Replace it.
The steel rope is abraded	No grease at installation or out of lifetime	Replace it.
Push down the release handle, but the carriage will not lower.	Damaged switch (SQ3) or poor wire connection.	Replace it or tighten the wire.
	Damaged unloading valve (YV) or poor wire connection.	Replace it or tighten the wire.

## INSPECTION AND MAINTENANCE

Easy and low cost routine inspection and maintenance can ensure the lift work normally and safely.

Follow the below routine inspection and maintenance schedule with reference to the actual working condition and frequency of your lift.

**Lubricate moving parts with NO.1 lithium based grease.**



Pos.	Components	Methods	Period
1	Hydraulic oil	Change the oil 6 months after initial use and once per year thereafter. Inspect the hydraulic oil and change the oil if the oil becomes black or there is dirt in the oil tank.	Every 6 months
2	Max lifting height limit switch	Use proper means to activate the switch and push UP button to check if the carriages stop rising.	Every month
3	Roof protection limit switch	Use proper means to activate the switch and push UP button to check if the carriages stop rising	Every month
4	Mechanical safety locking unit and descending movement	(1) Check if mechanical locking hooks can engage or disengage simultaneously.	Every day
		(2) Push maximally down the lowering handle, check if the carriages descend correspondingly.	
5	Upside pulley and steel rope	Lubricate the pulley and steel rope. Inspect and add more grease when necessary.	Every 3 months
6	Slider and its moving path	Lubricate the slider and its moving path inside the post. Change the slider when it is over worn.	Every 3 months
7	Cylinder connector	Check the hydraulic tightness of oil cylinder connector.	Every 3 months
8	Downside pulley and steel rope	Lubricate the pulley and steel rope. Inspect and add more grease when necessary.	Every 3 months
9	Lifting adapter	Check if it can screw UP and DOWN smoothly. Add grease onto the swivel when necessary. Inspect the rubber pads and clean off any objects that may cause sliding or damage.	Every day
10	Swing arm locking units	Push the UP button to raise the lifting arms and check if four swing arms are locked into position.	Every day
11	Expansion bolts	Check with torque spanner. Screw torque: 80-100N.m	Every 3 months
12	Steel ropes	Check the synchronization of both carriages and adjust the tightness of the rope if desynchronization is unacceptable.	Every day

*If users stick to the above maintenance requirements, the lift will always keep a good working condition and its service life could be extended.*

## Annex 1, Floor plan

**The lift is designed for indoor installation only. Do not expose the lift to rain, snow or excessive moisture. Do not use the lift near explosives or open areas containing inflammable liquids.**

The space requirement specified in the below scheme is for reference only.


There must be sufficient space for driving and lifting vehicles and enough safety distance shall be reserved according to the regulations of the local authorities. It is advised to reserve a clearance of at least 1 meter between the lift and fixed elements (e.g. wall) in all lifting positions.

C25/C30 concrete foundation with a minimum thickness of 200mm.


Surface under the base: Horizontal and even (Gradients max. 0.5 %)

Newly built concrete ground must be older than 20days.



All dimensions are in millimeters unless specified otherwise.



## Annex 2, Electrical schemes and parts list









YV: Solenoid valve for descending  
SQ1: Limit switch for roof protection  
SQ2: Limit switch for maximum height  
SQ3: Switch

Symbol	Code	Description	Qty
T	320104002	Transformer（380V400V415V-24V）	1
	320104001	Transformer（220V230V240V-24V）	1
QF	320801001	Circuit breaker（3Ph）	1
	320802001	Circuit breaker（1Ph）	1
QF1	320803001	Circuit breaker	1
QF2	320803003	Circuit breaker	1
KM	320901001	AC contactor	1
QS	320304001	Main switch	1
SQ1	320301002	Limit switch	1
SQ2	320301011	Limit switch	1
SQ3	320301003	Switch	1
	320503002	Wire terminals	1
SB1 SB2	320401042	Button	2
HL	321201001	Indicator light	1
	320505021	Wire terminal	1


### Annex 3, Hydraulic schemes and parts list



1. Oil tank
2. Oil sucking filter
3. Gear pump
4. Coupling
5. Motor
6. Hydraulic block
7. Cushion valve
8. Overflow valve
9. Single way valve
10. Solenoid valve for descending
11. Flow control valve
12. Tank cover
13. Composite connector
14. Oil cylinder




Pos.	Code	Descriptions	Specification	Qty
1		Power unit		1
2	207103025	Composite washer	13_7X20X1_5	5
3	310101008	Connector	M14*1.5-G1/4	1
4	624008106	Rubber oil hose	L=430mm	1
5	615006003	Three-way connector	6214E-A4-B4	1
6	624008215	Rubber oil hose	L=7660mm	1
7	624008211	Rubber oil hose	L=3115mm	1
8	615015003	Composite connector	6255E-A7-B7	2
9	625000013	Oil cylinder	YG5060-38-1800	2
9	625000013B	Oil cylinder (Replace 625000013 since April 11 <sup>th</sup> , 2025)	YG5060-38-1800	2




Pos.	Code	Descriptions	Specification	Qty
1+2	320204297+330404013	Motor + Coupling (54mm)	220V-2.2kW -1Ph-50Hz	1
	320204252+330404013	Motor + Coupling (54mm)	230V-2.2kW -1Ph-50Hz	1
	320204298+330404013	Motor + Coupling (54mm)	240V-2.2kW -1Ph-50Hz	1
	320204299+330404013	Motor + Coupling (54mm)	380V-2.2kW-3Ph-50Hz	1
	320204255+330404013	Motor + Coupling (54mm)	400V-2.2kW -3Ph-50Hz	1
	320204300+330404013	Motor + Coupling (54mm)	415V-2.2kW -3Ph-50Hz	1
	320204318+330404013	Motor + Coupling (54mm)	220V-2.2kW-1Ph-60Hz	1
	320204016+330404017	Motor + Coupling (52mm)	380V-3.0kW -3Ph-50Hz	1
	320201017+330404017	Motor + Coupling (52mm)	220V-2.2kW -3Ph-60Hz	1
	320201014+330404017	Motor + Coupling (52mm)	380V-2.2kW -3Ph-60Hz	1
3	210101014	Plug	Z3/8	1
4	207101187	O-ring	GB/T1235,16*2	2
5	210101019	Plug	YBZ1-PG06B	1
6	330302006	Non-return valve	DF08-01-00	1
7	330311016	Solenoid valve	DASV08-B20M-O-N	1
8	330405051	Plastic oil tank	10L-SLYX-10L-L-BX	1
10	202109144	Bolt	M5*18	1
11	330502013	Lid of oil tank (breather )	YBZ-BT-M30*2-B	1
12	330105088	Hydraulic block	YLBZ-T2KK-3	1
13	330304007	Relief valve	YF08-40	1
14	330305015	Flow-restrictive valve	YBZ-E2D311/1-11A	1
15	330600001	Transition connector	GJT-G1/4-9/16-18UNF	1
16	201101100	Bolt	M6*50(NJLD)	4
17	330301003	Buffer valve	HCF-Z1/4	1
18	207101098	O-ring	109*5.3	1
19	330201920	Gear pump (2.2kW-1Ph-60Hz)	CBKJ-F2.1F	1
	330201921	Gear pump (2.2kW-3Ph-50Hz/60Hz, 1Ph-50Hz)	CBKJ-F2.5F	1
20	330308045	Solenoid	LC2-08-C-08-H(AC24V)	1
21	320701088	Solenoid plug	AC24V	1
22	202109071	Hex socket cylinder head screw	M8x80-GB70_1	2
23	330402006	Oil-returning pipe	YBZ-E2D311/1-09	1
24	330401013	Oil-sucking pipe	YBZ-SJYG350	1
25	330403003	Oil-sucking filter	YBZ-E2D311/1-10	1


#### Annex 4, Mechanical exploded drawings and parts list



Pos.	Code	Description	Specification	Qty
1	615006015	Steel rope	L=10280mm	2
2	203101009	Hex nut	M16-GB6170	8
3	204101009	Flat washer	D16-GB95	4
4	410902109	Pulley	C9Z-A1-B2	2




Pos.	Code	Description	Specification	Qty
1		Power unit		1
2	624008106	Rubber oil hose	L=430mm	1
3	624008211	Rubber oil hose	L=3115mm	1
4	615015003	Composite connector	6255E-A7-B7	2
5	207103025	Composite washer	13_7X20X1_5	4
6	615006003	Three way connector	6214E-A4-B4	1
7	624008215	Rubber oil hose	L=7660mm	1
8	625000013	Cylinder	YG5060-38-1800	2
8	625000013B	Oil cylinder (Replace 625000013 since April 11 <sup>th</sup> , 2025)	YG5060-38-1800	2




Pos.	Code	Description	Specification	Qty
1	410902013	Spring	C9Z-A1-B10	2
2	410902014	Spring	C9Z-A1-B11	2
3	410010031	Washer	6254E-A1-B3	4
4	204301009	Circlip	D25-GB894_2	4
5	410902031	Shaft	C9Z-A1-B6	2
6	202111033	Hex socket flat head screw	M8x65-GB70_3	2
7	202109152	Hex socket cylinder head screw	M4X5-GB70_1	2
8	203101005	Hex nut	M8-GB6170	4
9	615068400	Handle assembly	C9Z-A1-B12	1
10	420680066	Nylon spacer	25X41X25	2
11	206102013	Elastic post pin	D6X40-GB879	2
12	615068399B	Locking hook assembly	C9Z-A1-B4-1	2
13	612901742	Release bracket	C9Z-A1-B5-V1	1
14	202109017	Hex socket cylinder head screw	M6X8-GB70_1	8
15	614006012B	Pulley	6214DS-A9	2
16	420080030	Pulley II	6214DS-A7	2
17	204301001	Circlip	D10-GB894_1	2
18	410540530	Release plate	C12-A1-B5-C1	1
19	410902484	Rope installation fitting	C9ZV2-A1-B13	2
20	410911492	Holder for the switch	C9ZV3-A1-B18	1







Pos.	Code	Description	Specification	Qty
1	410902494	Release steel rope	L=7640mm	1



Pos.	Code	Description	Specification	Qty
1	614901721	Crossbeam (outside)	C9MV2-A21-B1-1	1
2	202109024	Hex socket cylinder head screw	M6X35-GB70_1	1
3	203103005	Locking nut	M6-GB889_1	1
4	204101008	Flat washer	D14-GB95	5
5	204201007	Spring washer	D14-GB93	5
6	203101008	Hex nut	M14-GB6170	5
7	201102035	Hex head full swivel screw	M14X30-GB5783	5
8	420060010	Black foam tube	6214E-A21-B3	1
9	614901722	Crossbeam (inside)	C9MV2-A21-B2-1	1
10	410060013	Long rod	6214E-A21-B5	1
11	410902109	Pulley	C9Z-A1-B2	4
12	410902029	Space sheath	C9Z-A21-B4	2
13	205101101	Bearing	3520-SF-1X	4
14	612054507	Upside pulley shaft	C10S-A21-B3	2
15	202111004	Hex socket flat head screw	M8X12-GB70_3	2




Pos.	Code	Description	Specification	Qty
1	203103005	Locking nut	M6-GB889_1	2
2	410170101B	Cylinder orientation ring	6264-A24-B1	2
3	202109096	Hex socket cylinder head screw	M6X40-GB70_1	2
4	614901378	Carriage	C9Z-A3-B1-2	2
5	420680083	Sliding block	C9Z-A3-B5	16
6	420680124	Protective rubber pad	62B-A3-B11	2
7	202109031	Hex socket cylinder head screw	M8*30	4
9	410902001B	Pull rod	6254E-A2-B1-C1-1	4
10	410150121	Pressure spring	6254E-A2-B4	4
11	410901075	Teeth block	6254E-A2-B9	4
12	206102013	Elastic post pin	D6X40-GB879	4
13	204301009	Circlip	D25-GB894_2	4
14	202111004	Hex socket flat head screw	M8X12-GB70_3	2
15	612056001	Shaft for downside pulley	C12-A1-B3	2
16	205101101	Bearing	3520-SF-1X	2
17	410902109	Pulley	C9Z-A1-B2	2
18	210101018	Plastic protective cover	80X80mm	2



Pos.	Code	Description	Specification	Qty
1	204101008	Flat washer	D14-GB95	8
2	204201007	Spring washer	D14-GB93	8
3	203101008	Hex nut	M14-GB6170	8
4	201102035	Hex head full swivel screw	M14X30-GB5783	8
5	614901416	Extending post for power side post	C9MV2-A5-B1	1


Pos.	Code	Description	Specification	Qty
6	614901960	Power side post	C9MV3-A1-B1-V1	1
7	202109018	Hex socket cylinder head screw	M6X10-GB70_1	14
8	420680176	Control box frame	C9Z-A19-B2	1
9	420680175	Protective cover on the power side post	C9Z-A19-B1	1
10	615068210B	UP guiding pulley assembly	6214DS-A10-2	2
11	203204103	Flange nut	M8-GB6177	4
12	420040010	Anti-shock ring	6254E-A23	4
13	201101103	Bolt	M8X30-GB12	4
14	204101006	Flat washer	D10-GB95	4
15	614004009C	Mid arm	6254E-A27-B2	2
16	202109085	Hex socket cylinder head screw	M12X30-GB70_1	12
17	410901074	Semicircular teeth block	6254E-A7-B8	4
18	614004014B	Long fender	6254E-A7-B5	2
19	202110018	Hex socket cylinder head screw	M10X12-GB70_1	8
20	202109040	Hex socket cylinder head screw	M10X16-GB70_1	4
21	410049031B	Pin shaft	6254E-A12	4
22	614004005B	Long support arm	6254E-A7-B1	2
23	614901362	Retractable arm	6254E-A7-B3-1	2
24	615004003D	Lifting tray (no rubber pad)	6254E-A7-B4	4
25	420040250	Round rubber pad	6254E-A7-B4-C4	4
26	202111004	Hex socket flat head screw	M8X12-GB70_3	8
27	202101027	Cross socket cap head screw	M6X8-GB818	4
28	204101004	Flat washer	D6-GB95	8
29	614004011C	Retractable arm	6254E-A27-B3	2
30	614004007C	Short support arm	6254E-A27-B1	2
31	614004012B	Short fender	6254E-A27-B4	2
32	614901415	The secondary post	C9MV2-A2-B1	1
33	615064004B	Protective cloth assembly	C10Z-A8	2
34	614901417	Extending post for secondary post	C9MV2-A6-B1	1
35	203101004	Hex nut	M6-GB6170	8
36	204101004	Flat washer	D6-GB95	4
37	410010051	Hook for the covering cloth	6254E-A1-B5	4
38	615068406	Crossbeam assembly	C9MV2-A21	1
39	203103006	Hex locking nut	M8-GB889_1	4
40	420680096	Protective cover on the secondary post	C9Z-A1-B9-1	4
41	202109029	Hex socket cylinder head screw	M8X20-GB70_1	4

### Optional four low-profile 3-stage arms (615-1150, 745-1345)



Pos.	Code	Description	Specification	Qty
1	614901971	Lifting arm of long 3-stage arm (Right)	62CV3-A10-B1	1
2	614901972	Mid arm of long 3-stage arm (Right)	62CV3-A10-B2	1
3	614901973	Retractable arm of the long 3-stage arm (Right)	62CV3-A10-B3	1
4	202111004	Hex socket flat head screw	M8X12-GB70_3	8
5	420040250	Round pad	6254E-A7-B4-C4	4
6	610004547	Low-profile Lifting tray(no contact pad)	6254E-A7-B4-V1	4
4+5+6	610004517	Low-profile Lifting tray assembly	6254E-A7-B4-V2	4
7	410901074	Teeth block (semi-teeth)	6254E-A7-B8	4
8	202109085	Hex socket cylinder head screw	M12X30-GB70_1	12
9	410049031B	Pin shaft	6254E-A12	4
10	202110018	Hex socket cylinder head screw	M10X12-GB70_1	8
11	614004012B	Fender for the short 3-stage arm	6254E-A27-B4	2
12	204301013	Circlip	D38-GB894_1	4
13	614901976	Lifting arm of long 3-stage arm (left)	62CV3-A12-B1	1
14	614901977	Mid arm of the long 3-stage arm (left)	62CV3-A12-B2	1
15	614004030B	Fender for the long 3-stage arm	6254E-MDN-A10-B4	2
16	614901974	Lifting arm of short 3-stage arm (left)	62CV3-A11-B1	1
17	614901975	Mid arm of the short 3-stage arm (left)	62CV3-A11-B2	1
18	614901978	Retractable arm of the short 3-stage arm (left)	62CV3-A11-B3	1
19	614901968	Lifting arm of short 3-stage arm (Right)	62CV3-A9-B1	1
20	614901969	Mid arm of short 3-stage arm (Right)	62CV3-A9-B2	1
21	614901979	Retractable arm of the long 3-stage arm (left)	62CV3-A12-B3	1
22	614901970	Retractable arm of the short 3-stage arm (Right)	62CV3-A9-B3	1
23	204101006	Flat washer	D10-GB95	8
24	204201005	Spring washer	D10-GB93	8
25	202109041	Hex socket cylinder head screw	M10X20-GB70_1	4
26	202109040	Hex socket cylinder head screw	M10X16-GB70_1	4

### Optional height-extension adapter and holder



Pos.	Code	Description	Specification	Qty
1	612004003B	Height-extension adapter	6254E-A11,L=100	4
1	612005002	Height-extension adapter	6254EB-A4, L=55	4
2	410901744	Holder	6254E-A1-B1-C6-V0	2
3	202110004	Hex socket button head screw	M8X12-GB70_2	4